



# POLISHING SOLUTIONS FROM ENGIS® CORPORATION

Engis® is a world leader in the manufacture of diamond polishing compound. In fact, the very first product manufactured by Engis® at its inception in 1938 was diamond compound for high precision military applications. We now not only have 80+ years of manufacturing experience behind us, but have complemented it with expertise in both diamond characterization and carrier chemistry. Our ISO 9001 quality certification ensures that Engis® brings strict disciplines to our manufacturing processes.

At the very core of the Engis® Corporation is our "Systems Approach". We not only offer quality products for sale, but we also provide complete solutions to our customers' application challenges. For the mold and die polishing market this involves: Diamond compounds as well as other polishing products, rotary and reciprocating hand tools, and operator experience and techniques.



Engis® truly is a single source for all of your polishing needs. Because we recognize that polishing is a system, Engis® offers a full range of high quality rotary and reciprocating tools as well as machine accessories and consumables.

We know that it is customer service that will differentiate Engis® from other suppliers. Our total commitment to our customers means that we service everything we sell. You can purchase from Engis® knowing you will have complete factory support for technical questions and repairs.

And, to complete the package of total customer service, we have experienced tool and die makers on staff who can draw upon their own time on the bench to assist you with your polishing challenges or in selecting the right product.

In summary, at Engis® it is our intent to go beyond being just a provider of quality products, but to partner with our customers to provide the best possible finishes in the shortest amount of time and at the lowest cost.







### **TABLE OF CONTENTS**



# DIAMOND COMPOUNDS, POLISHING LUBRICANTS, & HIGH-INTENSITY POLISH

Section 1 — Diamold® Diamond Compounds 5 Hyprez® Lubricants 10 Diamold® High Intensity Polish 11



#### DIPROFIL® FINISHING SYSTEMS, TOOLS, & ACCESSORIES

Section 2 Diprofil® Finishing Systems 13 Diprofil® Classic Tools 14 Diprofil® Di-Pro™ Reciprocating Tools 15 Accessories for Classic and Di-Pro™ Tools 16 Electric Hanging Motors & Accessories 19 Bench Mount Motor Hangers 20 Classic Diprofil® Tool Kits 21 Foredom® Flex Shaft Rotary Handpieces 22 Diprofil® Micro-Motor Rotary Handpieces 22 Diprofil® Mini-Filing/Micro-Motor Systems 23 **Power Packs** 25 Diprofil® Ultrasonic System 26



#### DIPROFIL® FILES

Section 3 — Diprofil® Diamond & Steel Files — 27
Diprofil® Precision Diamond Files 29
Diprofil® Precision Hand Files 32
Diprofil® Precision Machine Files 39

Diprofil® Precision Steel Files

41



### MINIMO® FINISHING SYSTEMS, TOOLS, & ACCESSORIES

Section 4	Minimo® One Series	43
	Minimo® Power Packs	45
	Minimo® Polytor Ultrasonic	46
	Minimo® Standard Rotary Handpieces	47
	Minimo® Slender Rotary Handpieces	50
	Minimo® Heavy Duty Rotary Handpieces	51
	Minimo® Rubron Systems	54
	Minimo® Anglon Systems	55
	Minimo® Recipron Systems	63
	Minimo® Mini-Belt Sander	64
	Minimo® Motors	66
	Minimo® Heads	67
	Minimo® Accessories	70
	Minimo® Tool Stand/ Rubber Cradle	72



#### **ROTARY FINISHING TOOLS**

Section 5	Rotary Finishing Tools	<del></del> 73
	Engis® Superabrasive Tools	82



### FINISHING STICKS, STONES, & ACCESSORIES

Section 6	—— DiaMold® Lapping Sticks	85
	DiaMold® Polishing Stones	86
	DiaMold® Ceramic Stones	91
	DiaMold® Stone Holders	93
	Stones, Lapping Stick, & File Holders	94



#### **WELDING UNITS & ACCESSORIES**

Section 7	SST Microwelding —————	95
	Mold Medic Supplies	98

#### COMPOUNDS FOR EVERY APPLICATION

A comprehensive range of DiaMold® and Hyprez® Diamond Compounds for all variable involved in polishing. By using the proper compound, in conjunction with the proper equipment and accessories, you can be assured of consistent, repeatable results of the highest quality. Balancing our expertise in grading and micronizing of diamonds, along with knowledge of chemistry, compounding techniques, carrier formulations, and concentration factors, Engis® is able to offer every mold maker a compound to meet their specific need. Available in micron sizes from 1/10 to 60. Syringes sizes (grams): 5, 10, 18, 50, 100. Other container sizes are available.





Formulated for general purpose use, an economic solution that delivers quality results in many mold & die applications.

#### Hyprez®W Compound



Water soluble formula that cleans easily from the workpiece. Suitable for high luster polishing, but which might be affected by an oil-based compound.

#### Hyprez®L Compound



For use on harder materials, such as tungsten carbide tooling & ceramics due to enhanced surface tension properties. Withstands frictional heat generated during use.

#### Hyprez® SC Compound



Superior lubrication properties that enhance cut rate without sacrificing finish. Adheres to workpiece/ tool. High vaporization point permits working on precooled molds.

#### Hyprez®Five-Star



Combines the excellent cutting characteristics of natural diamond with the durability of synthetic diamonds, into an all-purpose, precision blend. Clean up with either oil or water-based products. Eliminates polishing steps, resulting in better quality finish produced in less time.

	Cher	nistry		Mate	erials		Po	erformance	
	Oil Based	Water Based	Carbides	Tool Steels	Ceramics	Aluminum	High Luster/ High Performance	Toolroom Applications	General Purpose
DiaMold®	•			•					•
Five Star	•	•	•	•		•	•		
L Compound	•		•		•	•		•	
W Compound		•					•	•	•
SC Compound	•		•		•				



### DiaMold® Compounds

#### PREMIUM PERFORMANCE AT AN ECONOMICAL PRICE

Not every polishing application demands a superior performing product and many customers are on a tight budget. For general use, Engis® offers the DiaMold® range of diamond compound.

Manufactured to the same specifications as our premium Five-Star\*compound, DiaMold\*compound offers an economical solution for mold and die polishing applications.

DiaMold® diamond compound is oil soluble and can be used with Hyprelube® and Hyprez® OS Type IV (oil soluble) lubricants.

#### **FEATURES & BENEFITS**

DiaMold'

- Economical
- Good surface tension
- Consistent viscosity
- Will not evaporate
- Oil based
- No odor
- · Good adhesion to tools and surfaces
- Use with OS or Hyprelube® lubricant

#### **AVAILABLE PACKAGING**

- 10 gram syringe
- 20 gram syringe
- · Call for other sizes

Micron Size	Product Code	Compound Color	Application	Concentration	10 Gram Part No.	20 Gram Part No.
1	1-DiaMold®	Ivory	Final Polishing	Standard	340.5120	340.5130
3	3-DiaMold®	Yellow	Final Polishing	Standard	340.5121	340.5131
6	6-DiaMold®	Orange	Lapping & Pre-Polishing	Standard	340.5122	340.5132
9	9-DiaMold®	Green	Lapping & Pre-Polishing	Standard	340.5123	340.5133
15	15-DiaMold®	Blue	Lapping & Pre-Polishing	Standard	340.5124	340.5134
30	30-DiaMold®	Red	Rapid Stock Removal	Standard	340.5125	340.5135
45	45-DiaMold®	Brown	Rapid Stock Removal	Standard	340.5126	340.5136
60	60-DiaMold®	Natural	Rapid Stock Removal	Standard	340.5127	340.5137

#### **VALUE KITS**

- 1 ea. 10 gram syringe 3, 6 & 9 (part no. 340.5144)
- 1 ea. 10 gram syringe 1, 3, 6 & 9 (part no. 340.5143)
- 1 ea. 10 gram syringe 9, 15 & 30 (part no. 340.5145)

#### DIAMOLD® FIVE-STAR® COMPOUND

The mold finisher's choice! Five-Star® compound is graded to closer tolerances than normal industry standards which results in faster and more consistent cut rates. Our Chemical Engineering Department has developed a carrier which offers superior finishes which can be cleaned with either oil or water based products.

The performance of Engis® Five-Star® compound often eliminates polishing steps, resulting in a better quality mold finish produced in less time.

2-Way Solubility: Five-Star\*diamond compound can be used with Hyprez\* OS Type IV (oil soluble) or Type W (water soluble) lubricants which offers maximum versatility.

#### FEATURES & BENEFITS



- Faster cut rates
- · Better finishes grit size to grit size
- · Excellent surface tension
- · Consistent viscosity
- · Will not evaporate
- · Excellent adhesion to tools and surfaces
- · Easily cleaned with water or oil based products
- Offered in Medium, Standard and Strong concentrations

#### **AVAILABLE PACKAGING**

- 5 gram syringe
- 18 gram syringe
- · Call for other sizes

Micron Size	Product Code	Compound Color	Application	Concentration	5 Gram Part No.	18 Gram Part No.
				Medium	204.1022	204.1023
1/10	1/10-FS/US	Gray	Final Polishing	Standard	204.1024	204.1025
				Strong	204.1026	204.1027
				Medium	204.1028	204.1029
1/4	1/4-FS/US	Gray	Final Polishing	Standard	204.1030	204.1031
				Strong	204.1032	204.1033
				Medium	204.1034	204.1035
1/2	1/2-FS/US	Gray	Final Polishing	Standard	204.1036	204.1037
				Strong	204.1038	204.1039
				Medium	104.1254	104.1255
1	1-FS/US	Ivory	Final Polishing	Standard	104.1256	104.1257
				Strong	104.1258	104.1259
		Yellow	Final Polishing	Medium	104.1260	104.1261
3	3 3-FS/US			Standard	104.1262	104.1263
				Strong	104.1264	104.1265
		Orange	Lapping &	Medium	104.1266	104.1267
6	6-FS/US		Orange	Pre-Polishing	Standard	104.1268
				Strong	104.1270	104.1271
			Lapping &	Medium	104.1272	104.1273
9	9-FS/US	Green	Pre-Polishing	Standard	104.1274	104.1275
				Strong	104.1276	104.1277
			Lapping &	Medium	104.1278	104.1279
15	15-FS/US	Blue	Pre-Polishing	Standard	104.1280	104.1281
				Strong	104.1282	104.1283
			Lapping &	Medium	104.1284	104.1285
30	30-FS/US	Red	Pre-Polishing	Standard	104.1286	104.1287
				Strong	104.1288	104.1289
			Lapping &	Medium	104.1290	104.1291
45	45-FS/US	Brown	Pre-Polishing	Standard	104.1292	104.1293
				Strong	104.1294	104.1295
			Lapping &	Medium	104.1296	104.1297
60	60-FS/US	Natural	Pre-Polishing	Standard	104.1298	104.1299
				Strong	104.1300	104.1301

#### HYPREZ® L COMPOUND

For tungsten carbine, hard metals, and ceramics. Hyprez® Formula L diamond coupounds are specially formulated for use with harder materials. Typical applications include finishing tungsten carbide tooling, rolls and balls, ceramics and coarse lapping on Hyprez® natural metal and special composite laps.

Proven formulation! Hyprez® Formula L is a uniform diamond particle suspension which is not affected by dilution. The compound can be thinned to any desired consistence with Hyprez® OS Type IV and Hyprelube® lubricants. It utilizes a special tension to improve lap adhesion.

Withstands frictional heat! The consistence of Hyprez® Formula L is not affected by frictional heat generated during use. Only minimal lubrication is required for optimal results.

#### FEATURES & BENEFITS



- · Formulated for carbide, ceramics, and hard metals
- Oil based
- Water based version available
- Offered in medium, standard, and strong concentrations
- Use with OS or Hyprelube® lubricant

#### **AVAILABLE PACKAGING**

- 5 gram syringe
- 18 gram syringe
- · Call for other sizes

Micron Size	Product Code	Compound Color	5 Gram Part No.	18 Gram Part No.
1/10	0.10(L)STD-MA	Gray	101.1002	101.1003
1/4	0.25(L)STD-MA	Gray	101.1022	101.1023
1/2	0.5(L)STD-MA	Gray	101.1042	101.1043
	1(L)MED-MA		101.1062	101.1063
1	1(L)STD-MA	Ivory	101.1082	101.1083
	1(L)STR-MA		101.1102	101.1103
	3(L)MED-MA	Yellow	101.1122	101.1123
3	3(L)STD-MA		101.1142	101.1143
	3(L)STR-MA		101.1162	101.1163
	6(L)MED-MA	Orange	101.1182	101.1183
6	6(L)STD-MA		101.1202	101.1203
	6(L)STR-MA		101.1222	101.1223
	9(L)MED-MA		101.1242	101.1243
9	9(L)STD-MA	Green	101.1262	101.1263
	9(L)STR-MA		101.1282	101.1283
	15(L)MED-MA		101.1302	101.1303
15	15(L)STD-MA	Blue	101.1322	101.1323
	15(L)STR-MA		101.1342	101.1343
	30(L)MED-MA		101.1362	101.1363
30	30(L)STD-MA	Red	101.1382	101.1383
	30(L)STR-MA		101.1402	101.1403
_	45(L)MED-MA		101.1422	101.1423
45	45(L)STD-MA	Brown	101.1442	101.1443
	45(L)STR-MA		101.1462	101.1463
	60(L)MED-MA		101.1482	101.1483
60	60(L)STD-MA	White	101.1502	101.1503
	60(L)STR-MA		101.1522	101.2121

7

#### **HYPREZ®W COMPOUND**

A water-soluable formula that cleans easily from the workpiece, Hyprez®W is recommended for areas requiring a very high luster, but which might be affected by an oil-base compound.

Hyprez®W was the first commercially successful diamound compound. Formulated by Engis®, it is still in general use by the die and mod industry and for precision hand lapping. For additional lubrication, use W lubricant.

#### FEATURES & BENEFITS



- Water based
- For parts requiring a higher luster
- Works great on 17-4 stainless
- Offered in medium, standard, and strong concentrations
- Use with W or Hyprelube® lubricants

#### **AVAILABLE PACKAGING**

- 5 gram syringe
- 18 gram syringe
- · Call for other sizes

Micron Size	Product Code	Compound Color	5 Gram Part No.	18 Gram Part No.
1/10	0.10(W)475-MA (STD)	Gray	102.1002	102.1003
1/4	0.25(W)475-MA (STD)	Gray	102.1022	102.1023
1/2	0.5(W)475-MA (STD)	Gray	102.1042	102.1043
	1(W)48-MA(MED)		102.1062	102.1063
1	1(W)47-MA (STD)	Ivory	102.1082	102.1083
	1(W)45-MA (STR)		102.1102	102.1103
	3(W)45-MA (MED)		102.1122	102.1123
3	3(W)40-MA (STD)	Yellow	102.1142	102.1143
	3(W)35-MA (STR)		102.1162	102.1163
	6(W)42-MA (MED)		102.1182	102.1183
6	6(W)375-MA (STD)	Orange	102.1202	102.1203
	6(W)30-MA (STR)		102.1222	102.1223
	9(W)40-MA (MED)		102.1242	102.1243
9	9(W)35-MA (STD)	Green	102.1262	102.1263
	9(W)30-MA (STR)		102.1282	102.1283
	15(W)40-MA (MED)		102.1302	102.1303
15	15(W)35-MA (STD)	Blue	102.1322	102.1323
	15(W)30-MA (STR)		102.1342	102.1343
00	30(W)40-MA (MED)	5.1	102.1362	102.1363
30	30(W)30-MA (STD)	Red	102.1382	102.1383
	30(W)20-MA (STR)		102.1402	102.1403
45	45(W)40-MA (MED)	Drown	102.1422 102.1442	102.1423 102.1443
45	45(W)30-MA (STD) 45(W)20-MA (STR)	Brown	102.1442	102.1443
	60(W)35-MA (MED)		102.1462	102.1483
60	60(W)30-MA (MED)	White	102.1482	102.1403
00	60(W)25-MA (STD)	VVIIILE	102.1502	102.1505
	00(VV)25-IVIA (5 I K)		102.1304	102.1505

#### HYPREZ® SC COMPOUND

Super-cut compound gets the job done quicker! The new Hypre's SC diamond compound has been specifically formulated with the polishing professional in mind. In the past, a compound that cut quickly might leave a higher finish, resulting in additional finishing steps to massage the mold back to its original state. Any time saved on the front end was lost in the final polish; to address this challenge the engineers at Engis\* have developed Hyprez\* SC.

An exceptionally sharp diamond particle type zhas been selected and the PSD (particle size distribution) optimized for superior cutting action.

In addition, the chemists at Engis® have formulated a new carrier with special lubricating properties which enhance the cut rate without sacrificing finish. Taking into consideration that larger molds must often be polished in situ, the carrier has a high vaporization point, which permits working on molds which have not yet cooled. Hyprez®SC takes the compromise out of polishing. This breakthrough formula results in faster stock removal and fewer polishing steps which lead to lower costs, improved productivity, and better quality components.

Hyprez® SC has been tested at premiere mold shops around the Midwest with successful results.

#### FEATURES & BENEFITS



- · New sharper diamond particles
- Optimized particle size distribution
- New carrier with superior lubrication qualities
- Better adhesion to the felt or wood bob
- Not "greasy" like standard compounds
- Easier to view the work piece while polishing
- · Higher vaporization point

#### **AVAILABLE PACKAGING**

- 5 gram syringe
- 20 gram syringe
- · Call for other sizes





Before and After photos of an A2 component finished with 3 micron SC compound on a felt wheel

Micron Size	Product Code	Compound Color	5 Gram Part No.	20 Gram Part No.
1	1(SC)STR	Ivory	500.1164	500.1168
3	3(SC)STR	Yellow	500.1174	500.1178
6	6(SC)STR	Orange	500.1124	500.1128
9	9(SC)STR	Green	500.1114	500.1118
20	20(SC)STR	Blue	500.1104	500.1108
30	30(SC)STR	Red	500.1134	500.1138
45	45(SC)STR	Brown	500.1144	500.1148
60	60(SC)STR	Natural	500.1154	500.1158



## **POLISHING LUBRICANTS**

#### Hyprez® Lubricants

When selecting a lubricant for your application, care should be taken that it is chemically compatible with the compound formulation that you intend to use.



#### PRODUCT DETAILS

#### Hyprelube<sup>®</sup>

Hyprelube® is a synthetic based lubricant formulated to be used with either our Five-Star® or our DiaMold® diamond compounds. This superior lubricant, with its penetrating qualities and oil/water solubility, not only increases the cutting action, but assures superior lubrication of every diamond particle throughout the polishing cycle.

#### OS Type IV Lubricant

This low-viscosity, oil soluble lubricant is compatible with DiaMold® and other oil-based diamond compounds.

#### W Lubricant

This water-based lubricant is compatible with Five-Star® and other water based compounds.

#### ALL HYPREZ® LUBRICANTS ARE AVAILABLE IN THE FOLLOWING CONTAINERS:

	Hyprelube <sup>®</sup> (Blue)	OS Type IV Lubricant (Purple)	W Lubricant (Yellow)
	There was a second of the seco		Hipport  Hip
4 oz. glass bottle	510.HL.4OZ	510.2030	510.W.4OZ
1 pt. glass bottle	510.HL.1PT	510.2029	510.W.1PT
1 qt. glass bottle	510.HL.1QT	510.2028	510.W.1QT
1 gal.	510.HL.1GA	510.2162	510.W.1GA
5 gal.	510.HL.5GA	510.2063	510.W.5GA



### HIGH INTENSITY POLISH

#### DiaMold® High Intensity Polish

DiaMold® High Intensity Polish (HIP) safely removes haze, plate-out, oxidation and stains from any metal surface.

It's ideal for the final finish on all types of molds and dies resulting in a high luster sheen without any harsh odors.

Being easier to remove than other polishes, DiaMold® HIP wipes off quickly without leaving any residue.

In addition, it is non-hazardous and non-corrosive and will clean and remove haze from the mold surface without causing spiral webs, cattails or other types of fine scratches.

#### **FEATURES & BENEFITS**

- No harsh odors
- · Easy application and removal
- · Imparts a high polished finish with very little effort
- Can be used on typical mold steels as well as brass, bronze, chrome and aluminum
- · Removes haze, rust, tarnish, dirt and oils
- Leaves protective film which retards oxidation and rust
- · Non-abrasive diamond formulation

#### **ORDERING GUIDE**

Size	Part No.
5 grams	HIP.5.SYR
10 grams	HIP.10
50 grams	HIP.50
250 grams	HIP.250
500 grams (1/2 kilo)	HIP.500
1,000 grams (1 kilo)	HIP.1000



#### DIAMOLD LABORATORY



Located in our Technical Center, the Diamold Laboratory is available to all customers for a "hands-on" opportunity to try our various hand tools, diamond compounds & lubricants, polishing accessories, and microwelder.

- · Experiment with different compounds
- · Demonstrations for polishing or welding
- · Authorized service center for hand tools & power packs
- Training





# DIPROFIL® FINISHING SYSTEMS

#### **Diprofil® Finishing Systems**

Engis® Corporation is proud to be a valued distributor of Diprofil® Finishing Systems and the exclusive factory authorized repair facility for all Diprofil® reciprocating and rotary tools. Our relationship with Diprofil® goes back more than 50 years, making Engis® the oldest Diprofil® distributor in North America.

In addition to the Diprofil® Classic Series, often imitated but never equaled, we stock the new Di-Pro™low vibration tools, Dipromini mini polishing machines, rotary tools and accessories.

The Diprofil® brand is well known for its robust construction, high torque, reliability and precision. Many Diprofil® tools see decades of service before requiring any type of repair. Not only does Engis® stock spare parts, but our technicians can give rapid turnaround on any warranty or service work. No other Diprofil® distributor can deliver on this promise!

So, for all of your Diprofil® reciprocating and rotary tool requirements, questions or service, contact the professionals at Engis® Corporation.

#### **AUTHORIZATION**

#### DIPROFIL®

Engis® Corporation has been authorized as

## AUTHORIZED DIPROFIL® SERVICE CENTER

Certified by:
Tomas Skeppmark
Managing Director, Diamantprodukter AB



#### **DIPROFIL® - TABLE OF CONTENTS**

Product	Page
Classic Reciprocating Polishing/Filing Tools	14
Di-Pro Low Vibration Reciprocating Tools	15
Accessories for Classic and Di-Pro Tools	16
Electric Hanging Motors & Accessories	19
Bench Mount Motor Hangers	20
Classic Tool Sets	21
Flex Shaft Driven Rotary Handpieces	22
Micro-Motor Driven Rotary Handpieces	22
Mini-Filing/Micro-Motor Systems	23
Power Packs	25
Diprosonic Ultrasonic System	26





#### **Diprofil® Classic Tools**

#### CLASSIC RANGE OF RECIPROCATING POLISHING/FILING TOOLS

The Classic Series is the original reciprocating filing tool designed as an efficient, fast, precise tooling system to replace tedious hand operations. Each tool is lightweight with sturdy construction, enabling operators to perform even delicate work on intricate parts with ease. The Classic Series is easy to operate and performs operations such as filing, honing, polishing and lapping of both straight and curved surfaces.

Classic tools have been the benchmark of quality tooling to mold and die making for many, many years.

	FPS/R	FPH/R	FPL/R
Each model is fit with an ergonomic rubber sleeve for maximum operator comfort!			

Motor	Motor Flexible Shaft with Flexible Shaft with ball joint ball joint		Air
Driver	Key hole	Square hole	Lubricated Compressed Air
Tool Holder	Dia. 6.4 mm	Dia. 6.4 mm	Dia. 6.4 mm
Stroke Length - Maximum	0 - 6mm	0 - 6mm	0 - 6mm
Stroke Length - Recommended	0.5 - 3mm	0.5 - 3mm	0.5 - 3mm
Speed - Maximum	8,000 rpm	8,000 rpm	8,000 rpm
Speed - Recommended	5,000-7,000 rpm	5,000-7,000 rpm	5,000-7,000 rpm
Weight	585 - 615 g	585 - 615 g	750 - 780 g
Noise	<70 dbA @ 6,000 rpm	<70 dbA @ 6,000 rpm	<70 dbA @ 6,000 rpm
Vibration	4 - 12 m/s <sup>2</sup>	4 - 12 m/s <sup>2</sup>	4 - 12 m/s <sup>2</sup>

Frequency weighed hand/arm vibration principally in accordance with ISO 28927-8. For further details refer to Operation Guide.

#### Diprofil® Di-Pro™ Reciprocating Tools

#### DI-PRO" MARK II - RANGE OF LOW VIBRATION RECIPROCATING TOOLS

The Di-Pro<sup>™</sup> polishing/filing machines represent a commitment from Diprofil® to greater operator comfort and safety. The Di-Pro<sup>™</sup> series has been engineered with an enhanced ergonomic design to greatly reduce vibration while, at the same time, providing adequate torque and reciprocation levels to get the job done right. With Di-Pro<sup>™</sup>, you don't need to sacrifice performance in order to improve comfort and safety!

	FXS-N	FXL-N
Each model is fit with an ergonomic rubber sleeve for maximum operator comfort!		
	Electric:	Air:

Motor	<ul> <li>Electric:</li> <li>Driven by electrical motor with speed control, ie Diprofil<sup>®</sup> type DSE-47 &amp; flexible shaft with ball joint connection.</li> <li>Corresponding motors of other brands may also be used.</li> </ul>	<ul> <li>Air:</li> <li>Should be driven by compressed air &amp; oil mist lubricated air.</li> <li>The built-in air motor may be damaged if operated with unlubricated air.</li> </ul>
Tool Holder	ø6.4mm	ø6.4mm
Stroke Length - Maximum	0 - 6mm	0 - 6mm
Stroke Length - Recommended	0.5 - 3mm	0.5 - 3mm
Speed-Maximum	7,000 rpm	7,000 rpm
Speed - Recommended	5,000 - 6,000 rpm	5,000 rpm
Weight	700 g	920 g
Noise	<75 dbA @ 7,000 rpm	<75 dbA @ 7,000 rpm
Vibration	<2.5 m/s <sup>2</sup>	<2.5 m/s <sup>2</sup>
Spare Parts List	http://diprofil.com/wp-content/uploads/2015/ 03/FXS-N-complete.pdf	http://diprofil.com/wp-content/uploads/2015/ 03/FXL-N-complete.pdf

It is important not to exceed the maximum tool input speed specified by the manufacturer.

Tools have been designed in accordance with ISO 28927-8 to minimize hand/arm vibration. For further details see diagram and other information in the Operation Guide.

Please note, the air-driven tool requires a quick coupling (HSLM) as well as an MFB Dipro-Fog lubricator. The air motor is manufactured to a precise level of accuracy and requires lubrication & filtered air (to 5 microns) to assure trouble-free operation.







### **ACCESSORIES**

#### Accessories for Classic and Di-Pro™ Tools

#### UNIVERSAL TOOL HOLDER FMR/VH

Designed for Diprofil® polishing/filing machines. Great choice for holding DiaMold polishing stones.

#### FE

#### **FEATURES**

- · Stainless steel hardened shank 3mm (1/8")
- · Shank length approximately 35mm (1.375")
- · Maximum tool thickness 6mm (.236")



#### **LIGHTWEIGHT TOOL HOLDER THPS-3**

The reduced mass design of this tool holder suppresses potentially harmful vibrations from the stoning operation. Designed to be used with Diprofil® reciprocating machines and polishing stones with a thickness of 3mm (1/8").

#### **FEATURES**

- · Stone thickness capacity 3mm (1/8")
- Steel hardened shank 3mm (1/8")
- Shank length approximately 18mm (11/16")
- Total tool holder length 31.5mm (1-1/4")
- Jaw width 8mm (5/16")
- Weight 3.9g





#### LIGHTWEIGHT TOOL HOLDER THFS-1

The reduced mass design of this tool holder suppresses potentially harmful vibrations from the stoning operation. Designed to be used with Diprofil® and other high frequency ultrasonic machines using ceramic stones with a thickness of 1mm (.039").



#### **FEATURES**

- Ceramic stone thickness capacity 1mm (.039")
- Steel hardened shank 3mm (1/8")
- Shank length approximately 18mm (11/16")
- Total tool holder length 31.5mm (1-1/4")
- Jaw width 8mm (5/16")
- Weight 4.3g





#### PROTECTIVE FINGER SLEEVES PFS-3.5 AND PFS-6.4

The PFS-3.5 and PFS-6.4 Protective Finger Sleeves are designed to fit your existing Diprofil® Classic and Di-Pro Series machines. This attachment covers the reciprocating tool rods and greatly reduces hand injuries during sustained tool operation.

#### FEATURES

- · PFS-3.5 fits machines with a 3.5mm tool capacity
- · PFS-6.4 fits machines with a 6.4mm tool capacity





Old (wrong) way

→ New (correct) way

#### FNAK LUBRICATING OIL FOR DIPROFIL® TOOLS

FNAK Lubricant is specially formulated for use on external oil points on Diprofil® hand tools. When used properly this oil will reduce wear and prolong the life of your Diprofil® reciprocating polishing/filing machines.

Part No.	Container Size	MSDS
FNAK	20 ml / .67 oz	659
FNAK-0.5	1/2 liter / 16.9 oz	659



Please note: It is recommended that you read and follow the procedures outlined in the manufacturer's Operation Guide sent with each tool as they may require daily, as well as hourly, lubrication.

#### MFB DIPRO-FOG IN-LINE AIR FILTER/ LUBRICATOR/ REGULATOR/ MANOMETER

When using any Diprofil® air operated tool, the MFB In-Line Air Lubricator is a MUST. The MFB not only serves as a micro particle air filter, but keeps the pressure constant and the unit lubricated. The MFB set includes tubing and a bottle of MFAK tool lubricant. We also recommend ordering the HSLM quick release hose connector when using Diprofil® air operated tools.

#### **TECHNICAL DATA**

- Max. primary pressure: 16 bar / 232 psi
   Max. capacity at 7 bar: 1200 l/min
- Hose connection: 7mm / .275"
- Secondary pressure: 0.5 10 bar / 7 145 lbs



Please note: If your shop air has heavy contamination of dirt, oil, or water, it is advisable to add a larger pre-filter to reduce contamination to 5 micron.

#### MFAK DIPRO-FOG LUBRICANT

The Dipro-Fog MFAK Oil is specially developed for the unique lubricating requirements of the Diprofil and the Air Rotary Handpieces through the Dipro-Fog MFB Air Lubricator.

Part No.	Container Size	MSDS
MFAK	1/2 liter / 16 oz	659



#### **HSLM QUICK RELEASE HOSE CONNECTOR**

Each air-driven machine requires a quick coupling connector (type HSLM) as well as a Dipro-Fog lubricating device (MFB) to ensure sufficient lubrication at all times.



#### **DEMONSTRATION**

### To view a Diprofil® demonstration, visit www.diprofil.com/diprofil-english/videos/



#### **Electric Motors & Accessories**

#### M.TX-SXR Kit

#### High Torque / Low Speed Key Drive Type 1/3 HP 15,000 maximum rpm Ball Bearing Design 115V Electrical Plug



#### M.LXH-TXR Kit

#### High Torque / Low Speed Square Drive Type 1/10 HP 5,000 maximum rpm Ball Bearing Design 115V Electrical Plug



#### M.TX-TXR Kit

#### Extra Torque / High Speed Key Drive Type 1/3 HP 15,000 maximum rpm Ball Bearing Design 115V Electrical Plug



#### Includes:

- · M.TX Hang Up Style Motor
- · C.SXR-1 Cast Iron Foot Pedal
- Outer Sheath #S-77 (36-1/4" long)
- Inner Key Drive Shaft S-93 (39" long)

#### Includes:

- · M.LX Hang Up Style Motor
- · C.TXR-1 Plastic Foot Pedal
- Heavy Duty Outer Sheath #S-10801TX (63" long)
- Inner Shaft #S-10823 (63-3/4" long)

#### Includes:

- · M.TX Hang Up Style Motor
- C.TXR-1 Plastic Foot Pedal
- Outer Sheath #S-77 (36-1/4" long)
- Inner Key Drive Shaft S-93 (39" long)

#### **Replacement Parts:**

- C.SXR-1 Speed Control (foot pedal)
- Outer Sheath #S-77 (36-1/4" long)
- Inner Key Drive Shaft #S-93 (39" long)
- MP319P Motor Brushes & Brush Caps

#### **Replacement Parts:**

- C.TXR-1 Speed Control (foot pedal)
- Heavy Duty Outer Sheath #S-10801TX (63" long)
- Inner Shaft #S-10823 (63-3/4" long)
- MP319P Motor Brushes & Brush Caps

#### **Replacement Parts:**

- C.TXR-1 Speed Control (foot pedal)
- Outer Sheath #S-77 (36-1/4" long)
- Inner Key Drive Shaft #S-93 (39" long)
- MP319P Motor Brushes & Brush Caps

#### Hand Tools That Use M.TX-SXR:

- FXS-N Di-Pro Machine (page 11)
- FPS/R Classic Machine (page 10)

#### Hand Tools That Use M.LX:

H.30H, H.44T

#### Hand Tools That Use M.TX-TXR:

FPS/R

#### C.EMX-1 RHEOSTAT DIAL SPEED CONTROL



Solid state motor speed control offers precise adjustment of motor speed and maintains speed for the operator unlike a foot pedal that requires constant foot pressure.

#### **Bench Mount Motor Hangers**

#### MAMH-2 BENCH TOP SCREW MOUNT

The Telescoping Motor Hanger is designed for fast and easy height and swivel adjustment by way of pole screws.


The pole base flange mounts permanently to your workbench top by three screws providing secure stable mounting. (Motor not included.)



#### MAMH-1 BENCH TOP CLAMP MOUNT

This motor hanger allows you the flexibility to move the hanger assembly easily to any bench location by way of its screw clamp (2 1/4") capacity.

It also includes rest for #30 or #44 handpieces. (Motor and handpieces not included.)



#### MAHH-30 BENCH HANDPIECE HOLDER CLAMP

The MAHH-30 provides a secure bench-top mounting of handpieces #30 and #44 (see page 18).

With the handpiece firmly held to the bench top, the operator has both hands free to hold and control the workpiece during grinding or polishing operations. (Handpiece not included.)



Adjust height

### Classic Diprofil® Tool Kits

#### DS4 - FPS/R CLASSIC TOOL WITH KEY DRIVE KIT (39" CABLE)

#### **SET INCLUDES:**

- FPS/R: Classic Diprofil®Tool with Key Drive
- M.TX-TXR: Drive motor with key drive flex shaft & foot control
- MAMH-1: Bench clamp motor hanger
- C.TXR-1: Foot pedal
- S-77: Outer sheath
- S-93: Inner key drive shaft
- · MP319P: Motor brushes & caps



#### **FEATURES**

- Tool holder: 6.4 mm / 1/4"
- Stroke length: 0-6 mm / 0-.235"
- Motor: 5,000 rpm

#### DS5 - FPH/R CLASSIC TOOL WITH SQUARE DRIVE KIT (HEAVY DUTY 63" CABLE)



#### **SET INCLUDES:**

- FPH/R: Classic Diprofil® Tool with Square Drive
- M.LXH-TXR: Drive motor with square drive flex shaft and foot control
- MAMH-1: Bench clamp motor hanger
- · C.TXR-1: Foot pedal
- S-10801TX: Outer sheath
- S-10823: Inner square drive shaft
- MP319P: Motor brushes & caps



#### **FEATURES**

- Tool holder: 6.4 mm / 1/4"
- Stroke length: 0-6 mm / 0-.235"
- Motor: 5,000 rpm

#### Foredom® Flex Shaft Rotary Handpieces

#### MODEL H.30 HANDPIECE WITH KEY DRIVE

The Model 30 Handpiece features a 3 jaw chuck with a shank accessory capacity of 0 to 5/32" (4mm).

Supplied with a #72 Chuck Key, the greased sealed ball bearings provide long trouble-free operation.

This handpiece is driven by a flex shaft drive motor with key drive and a TXR foot pedal speed control.



#### MODEL H.44T HANDPIECE WITH KEY DRIVE

The Model 44 Handpiece accommodates rotary accessories with shank sizes up to 1/4" diameter. It is supplied with three collets (3/32", 1/8" and 1/4"), spindle lock pin and collet wrench. This Handpiece is driven by a flex shaft drive motor with key drive and a TXR foot pedal speed control.

Part No.	Capacity	Range
442	3/32"	.085" to .093"
443	1/8"	.113" to .125"
444	5/32"	.144" to .156"
445	3/16"	.177" to .187"
447	1/4"	.238" to .250"



#### Diprofil® Micro-Motor Rotary Handpieces

#### **DIPROFIL ROTARY HANDPIECE C-HPM-B1**

This micro-motor driven rotary handpiece with carbon brush motor is used together with power unit DPU-3 or the twin power controller Marathon HA-700. It features a quick change design for both the collet and the tool. Supplied with 3.0mm collet; optional 2.35mm collet is available.

#### TECHNICAL DATA


Speed Maximum: 38,000 rpmConsumed power: 100 W

Torque: 4.0N cm
Weight: 285 g
Vibration: 2.5 m/s<sup>2</sup>



#### DIPROFIL® BRUSHLESS ROTARY HANDPIECE C-HPM-BL1

A micro-motor driven high speed rotary handpiece with brushless motor for use with HA-700 Marathon twin controller. It features a quick change design for both the collet and the tool. Supplied with 3.0mm collet; optional 2.35mm collet is available.



Speed Maximum: 40,000 rpmConsumed power: 230 W

Torque: 7.6N cmWeight: 350 g


• Noise: < 70 db(A) at 40,000 rpm

Vibration: 2.5 m/s<sup>2</sup>



#### DIPROFIL® BRUSHLESS ROTARY HANDPIECE C-HPM-BL2

A micro-motor driven ultra high speed rotary handpiece with brushless motor for use with HA-700 Marathon twin controller. It features a quick change design for both the collet and the tool. Supplied with 3.0mm collet; optional 2.35mm collet is available.



Speed Maximum: 50,000 rpmConsumed power: 230 W

Torque: 7.6N cmWeight: 350 g

• Noise: < 70 db(A) at 50,000 rpm

Vibration: 2.5 m/s<sup>2</sup>



#### Diprofil® Mini-Filing/ Micro-Motor Systems

#### DIPROMINI TRANSVERSE POLISHING/FILING MACHINE FMV/D

The Dipromini Transverse Polishing/Filing Machine provides left-to-right transverse movement of the head. This tool requires a HPM-B1 brush motor controlled by a DPU-3 power unit or HA-700 Marathon twin power unit.

#### TECHNICAL DATA

• Tool holder: Max. Ø3.5 mm

Stroke length: Variable stroke 0-4 mm (measured 60 mm from the machine housing)

 Speed: Max.12,000 rpm at 2 mm stroke length (Recommended 6,000 - 10,000) rpm

Dimension: Ø24 mm
 Weight: 195 - 240 g

• Noise: <75 dB(A) at 12,000 rpm

Vibration: <2.5 m/s<sup>2</sup>



Frequency weighed hand/ arm vibration, principally in accordance with ISO 28927-8. For further details, see diagram and other information in the Operation Guide.

#### DIPROMINI RECIPROCATING POLISHING/FILING MACHINE FMR/D

The Dipromini Reciprocating Polishing/Filing Machine provides forward-back reciprocating movement of the head. It requires a HPM-B1 brush motor controlled by a DPU-3 power unit or HA-700 Marathon twin power unit. Available with three different stroke lengths:

Stroke Length	Part Number	Vibration
0.5 mm	FMR/D5	< 2.5 m/s <sup>2</sup>
1.0 mm	FMR/D10	< 2 - 2.8 m/s <sup>2</sup>
1.5 mm	FMR/D15	< 2 - 2.5 m/s <sup>2</sup>



#### TECHNICAL DATA

Tool holder: Max. Ø3.5 mm
 Stroke length: 0.5.1.0 or 1.5 mm

• Stroke length: 0.5, 1.0 or 1.5 mm

 Speed Maximum: 10,000 rpm (Recommended: 5,000 -8,000 rpm)

Dimension: Ø24 mmWeight: 120 g

• Noise: <70 dB(A) at 7,000 rpm

Frequency weighed hand/arm vibration, principally in accordance with ISO 28927-8. For further details, see diagram and other information in the Operation Guide.

#### MICRO-MOTOR HPM-B1

The DC Brush Micro-Motor powers the Diprofil Mini Polishing/Filing Machine types FMR/D, FMV/D and rotary handpiece type C-HPM-B1. This motor is controlled by a DPU-3 power unit or HA-700 Marathon twin power unit.

#### **TECHNICAL DATA**

Speed maximum: 38,000 rpmConsumed power: Max. 100 W

Torque: 4.0N cmWeight: 190 g

Dimensions: L100 x Ø29.5 mm
 Noise: <70 db(A) at 38,000 rpm</li>

Vibration: <2.5 m/s<sup>2</sup>



#### **BRUSHLESS MICRO-MOTOR HPM-BL1**

The Brushless Micro-Motor powers the Di-Pro FXV/D Polishing/Filing Machine. This brushless motor is controlled by a HA-700 Marathon twin power unit.



Speed maximum: 40,000 rpmConsumed power: Max. 230 W

Torque: 8.5N cmWeight: 255 g

Dimensions: L100 x Ø27 mm
 Noise: <70 db(A) at 40,000 rpm</li>


• Vibration: <2.5 m/s<sup>2</sup>



#### **Power Packs**

#### **DIPROFIL® POWER UNIT DPU-3**

This compact and ergonomic power unit replaces the DPU/2 and is designed for use together with dedicated rotary handpieces and micro-motor driven reciprocating Diprofil® polishing/filing machines with carbon brush motors. It has high torque and electrical feedback circuitry. Other features include continuously variable speed, forward/reverse switch and automatic overload protection. The DPU-3 is supplied with foot control DPU-3-FC for optional speed adjustment.



• Input: AC 110/220 V at 50/60 Hz

Output: DC 0 - 32 V, 1.2 A

Power: Max. 100 W

• Weight Power Unit: 1.7 kg

• Dimensions Power Unit: W115 x D147 x H96 mm

· Weight Foot Control: 585 g



For brush-type motors only

#### **HA-700 MARATHON TWIN POWER UNIT**

The Marathon Twin Power Unit features the versatility of powering and controlling carbon brush motors as well as brushless micro-motors (not simultaneously). The HA-700 offers hand dial variable speed control with digital display, forward/reverse switch and automatic overload protection.

#### TECHNICAL DATA

• Input: AC 200 ~ 240 V at 50/60 Hz

Output: DC 0 - 32 V, 1.6 A

BLDC 0 - 32 V, 1.6 A

· Power DC: Max. 185 W

• Power BLDC: Max 245 SW

· Weight Power Unit: 2.9 kg

Dimensions Power Unit: W137 x D232 x H180 mm

• Weight Foot Control: 575 g



#### HA-700 MARATHON TWIN POWER UNIT (CONT.)

#### **TECHNICAL DATA**

- · Supports brush and brushless type motors
- · Easy to read digital display showing speed in rpm
- · Precise rheostat speed dial control from 1,000 -50,000 rpm
- · Drives tools with high torque at all speeds for unstoppable power
- · Error code display function /self diagnosis system

Caution: Be sure to remain within manufacturer's rpm recommendation for tool.

#### Diprofil® Ultrasonic System

#### DIPROSONIC DUS-300 ULTRASONIC FINISHING/ POLISHING SYSTEM FROM DIPROFIL®

The main advantage of the Diprosonic DUS-300 Ultrasonic Finishing/Polishing System is its very short stroke length (10 - 35 mm) at a very high frequency (18 - 25 kHz). This makes this unit ideal for working in narrow and confined spaces such as cavities and slots where a short stroke length is preferable. For this kind of delicate work, the Diprosonic will give you precise finishing with rapid stock removal in a relatively clean environment without the need for lubricating fluids, etc.

The unit is excellent for use together with ceramic fiber stones and sintered diamond files, but it is also possible to use electroplated diamond files as long as the shank of the used tool is kept as short as possible.

Operation is either by hand or the included foot switch and the unit will automatically find the right frequency for each tool.

#### **FEATURES & BENEFITS**

- 36 W max. output
- · Two output levels (high/low)
- Capable of long working periods
- · Auto feedback system
- · Small, compact and low weight

#### **TECHNICAL DATA**

#### **Control Unit:**

Input: AC 90 - 220 V, 50/60 Hz

· Ultrasonic Power Output: 36 W

· Frequency: 18 - 25 kHz

Stroke: 10 - 35 mm

• Dimensions: 144W x 195D x 95H mm

· Weight: 658 g

#### Handpiece:

· Cord length: 1500 mm

Dimensions: o 30 x 131 mm

Weight 185 g

#### SYSTEM INCLUDES

- Ultrasonic Handpiece for DUS-300 (DUS-300-HP)
- Handpiece Cable (DUS-5)
- Power Cord US type 110V (DUS-6)
- Foot switch (DUS-300-FS)
- 10/11 mm Spanner (DUS-8)
- 2.5 mm Hex-key (DUS-9)
- Handpiece stand (DUS-10)
- Tool-holder 1.1 mm (DUS-11)
- Tool-holder dia. 3 mm (DUS-30)

- Tool Kit Complete\* (DUS-300-TK), consisting of 1 ea.
  - Fiber Stone 4 x 1 x 50 mm, 250 grit
  - Fiber Stone 4 x 1 x 50 mm, 400 grit
  - Fiber Stone 4 x 1 x 50 mm, 700 grit
  - Fiber Stone 6 x 1 x 50 mm, 250 grit
  - Fiber Stone 6 x 1 x 50 mm, 400 grit
  - Fiber Stone 6 x 1 x 50 mm, 700 grit
  - · Sintered Diamond File DLU-641, 400 grit · Sintered Diamond File DLU-642, 600 grit
  - Sintered Diamond File DLU-740, 200 grit
  - · Sintered Diamond File DLU-741, 400 grit



Engis reserves the right to change or substitute standard accessories



# DIPROFIL® FILES

#### Diprofil® Diamond and Steel Files

Diprofil® Diamond Files are made from carefully selected quality diamonds, precisely bonded to obtain the best physical properties for added strength and resistance to wear. Diamond files are excellent for EDM scale removal and for use on carbide, hardened steel, ceramics and other hard materials.

Page	Туре	Intended Use
29	DLA	Short machining files for general use. Designed with a semi-flexible shank to obtain a good contact with the work piece. These precision files are the basic type for use with the Diprofil Polishing Machines. Different shapes and grain sizes are available as well as safe-sided types. Medium to high stroke (3-5 mm).
30	DLE	Long precision machine files for general use. Low to medium stroke (2-4 mm). Different shapes and grain sizes are available as well as two safe-sided types. Low to medium stroke (2-4 mm).
30	DLF	Precision riffle type machine files. Especially recommended for use on shaped surfaces. Available in both medium and coarse diamond grains.
31	DLK	Large machine files for use together with the heavy-duty type machines with Ø6.4mm tool holder. Max 4 mm stroke recommended to avoid high levels of vibrations. Different shapes available as well as a safe sided type.
32	DLN	Precision mini hand files for delicate work. Different shapes.
32	DLG	"Habilis" type diamond hand files for general use. This file type can be comfortably used without a fitted handle.
33	DLH	Precision hand files for general use. Different shapes available as well as safe-sided types.
33	DLS	Conical hand files for general use. Specially recommended for EDM scale removal and other preparation of thin slots, e.g. after wire-EDM machining. Different sizes and grain sizes are available.
34	DBH	Hand files for general use.
35	DLL	Short conical hand files for general use. Specially recommended for EDM scale removal and other preparation of thin slots, e.g. after wire-EDM machining. Different sizes and grain sizes are available.
36	DLD	One sided riffle type hand files. Specially recommended for use on shaped surfaces.
37	DLX	Hand files for general use. This file type can be comfortably used without a fitted handle.
38	DLQ	Extra long (200 mm) hand files for general use. Different shapes are available.


Page	Туре	Intended Use
39	DLM	Short conical machine files for general use. Specially recommended for EDM scale removal and other preparation of thin slots, e.g. after wire-EDM machining. Different shapes and grain sizes are available
40	DBE	Long machine files for general use. Low to medium stroke (2-4 mm). Different shapes and grain sizes are available.
41	DLB	Riffle type machine files. Especially recommended for use on shaped surfaces.

Diprofil® Precision Steel Files are great for use on soft and semi-hard steel as well as other materials of low and medium hardness.

Page	Туре	Intended Use
41	STL-1 – STL-6	Standard steel files for use in Diprofil polishing machines. Low to medium stroke (2-4 mm). Available in both medium (-00) and fine (-1) cut as well as in different shapes.
41	STL-11 – STL-16	Precision riffle type machine files. Especially recommended for use on shaped surfaces. Low to medium stroke (2-4 mm). Available in both medium (-00) and fine (-1) cut as well as in different shapes.
42	STL-21 – STL-26	Mini steel files for use in Diprofil polishing machines. Low to medium stroke (2-4 mm). Available in both medium (-00) and fine (-1) cut as well as in different shapes.
42	STL-101	Medium sized steel files especially recommended for deburring of cast aluminum goods. Low to medium stroke (2-4 mm). Available in both medium (-00) and fine (-1) cut.


### Diprofil® Precision Diamond Files

#### DLA PRECISION FILES FOR DIPROFIL® FILING MACHINES




Shape	Size mm	Diamond D64* • 50 (fine)	Diamond D151* • 100 (medium)	Diamond D181* • 150 (coarse)
Standard Files			,	( ,
	2 x 1	DLA-2x1S	DLA2x1S-D151	DLA2x1S-D181
	3 x 1	DLA-3x1S	DLA3x1S-D151	DLA3x1S-D181
	4 x 1	DLA-4x1S	DLA4x1S-D151	DLA4x1S-D181
<u> </u>	4 x 2	DLA-4x2S	DLA4x2S-D151	DLA4x2S-D181
	5 x 2	DLA-5x2S	DLA5x2S-D151	DLA5x2S-D181
	Ø1	DLA-1	DLA-1	DLA-1
	Ø2	DLA-2	DLA-2	DLA-2
$\bigcup$	Ø3	DLA-3	DLA-3	DLA-3
	Ø4	DLA-4	DLA-4	DLA-4
	2 x 2 x 2	DLA-T2S	DLA-T2S	DLA-T2S
	3 x 3 x 3	DLA-T3S	DLA-T3S	DLA-T3S
	4 x 4 x 4		DLA-T4S	DLA-T4S
	r = 1		DLA-R1S	
	r = 1.5		DLA-R1.5S	
	r = 2	DLA-R2S	DLA-R2S	DLA-R2S
	r = 5	DLA-R2.5xR5	DLA-R2.5xR5	DLA-R2.5xR5
	r = 2.5			
Safe-Sided Files	5			
	2 x 1	DLA-2x1	DLA-2x1	DLA-2x1
	3 x 1	DLA-3x1	DLA-3x1	DLA-3x1
	4 x 1	DLA-4x1	DLA-4x1	DLA-4x1
	4 x 2	DLA-4x2	DLA-4x2	DLA-4x2
	5 x 2	DLA-5x2	DLA-5x2	DLA-5x2
	0.5 x 4		DLA-0.5x4	
	0.75 x 4		DLA-0.75x4	
	1 x 4		DLA-1x4	DLA-1x4
٨	2 x 2 x 2	DLA-T2	DLA-T2	DLA-T2
	3 x 3 x 3	DLA-T3	DLA-T3	DLA-T3
	4 x 4 x 4		DLA-T4	DLA-T4
	r = 1		DLA-R1	
	r = 1.5		DLA-R1.5	
_	r = 2	DLA-R2	DLA-R2	DLA-R2

#### DLE PRECISION FILES FOR DIPROFIL® FILING MACHINES



Shape	Size mm	Diamond D151* • 100 (medium)	Diamond D181* • 150 (coarse)			
Standard Files						
	5 x 1	DLE11-D151	DLE11-D181			
	Ø3	DLE2	DLE2-D181			
	5 x 2	DLE30-D151				
$\bigcirc$	5 x 2	DLE4				
	3.5 x 3.5 x 3.5	DLE5	DLE5-D181			
$\triangle$	☑2.5	DLE6	DLE6-D181			
Safe-Sided Files						
	5 x 1	DLE1	DLE1-D181			
	5 x 2	DLE3				

#### **DLF PRECISION FILES FOR DIPROFIL® FILING MACHINES**



Shape	Size mm	Diamond D151* • 100 (medium)	Diamond D181* • 150 (coarse)
Standard Files			
	4.5 x 2.5	DLF-1	DLF-1
	Ø3	DLF-2	DLF-2
	5 x 2.5	DLF-4	DLF-4
	3 x 3	DLF-6	DLF-6

\*Grain Sizes according to FEPA

#### DLK PRECISION FILES FOR DIPROFIL® FILING MACHINES

	Shape	Size mm	Diamond D151* • 100 (medium)
	Standard Files		
140 mm		10 x 2.5	DLK-11
140 mm		Ø6.3	DLK-2
1.12.5 m		12.2 x 3.7	DLK-3
146 ptrei	$\triangle$	9.6 x 9.6 x 9.6	DLK-5
100 mm		<b>⊠</b> 5.3	DLK-6
	Safe-Sided Files		
95 mm 97 mm 97 mm		10 x 2.5	DLK-1

	Diamond D64* • 50 (fine)	Diamond D151* • 100 (medium)	Diamond D181* • 150 (course)
18 mm For use with Tool Holder FBA-2	DLC-7x18	DLC-7x18	DLC-7x18
O.J. mm For use with Tool Holder SEV	DLC-7x18	DLD-10	DLD-10
3.3 min		DTA	

### Diprofil® Precision Hand Files

#### **DLN PRECISION FILES FOR DIPROFIL® FILING MACHINES**

140 mm	Shape	Size mm	Diamond D151* • 100 (medium)
- 41 mm - +		4 x 1.3	DLN-1
		Ø1.6	DLN-2
		4 x 1.8	DLN-3
	$\bigcirc$	4 x 1.6	DLN-4
ide i la minima de la compania de l	$\triangle$	3 x 3 x 3	DLN-5
		<b>⊠</b> 1.9	DLN-6
		4.1 x 1.5	DLN-7
Shaft diameter 3mm	File set contain	ning 7 files, one to DLN-7.	DLN-100

#### DLG PRECISION FILES FOR DIPROFIL® FILING MACHINES

215 mm	Shape	Size mm	Diamond D151* • 100 (medium)
(+ 110 mm - +		10.3	DLG-1
		Ø6.5	DLG-2
		12 x 4	DLG-3
	$\triangle$	9.5 x 9.5 x 9.5	DLG-4
		<b>Ø</b> 5.5	DLG-5
Shaft diameter 6mm	File set contain	ning 5 files, one o DLN-5.	DLG-100

#### **DLH PRECISION HAND FILES**


+ 140 mm →	Shape	Size mm	Diamond D151* • 100 (medium)
€   -		5.3 x 1.4	DLH-11
5		Ø3	DLH-2
	$\bigcirc$	5.1 x 2.2	DLH-4
E Belling Angelin and Committee and Committe	$\triangle$	3.8 x 3.8 x 3.8	DLH-5
		☑2.6	DLH-6
		5.2 x 1.6	DLH-8
		5.0 x 1.6	DLH-9
	$\Diamond$	5.0 x 2.4	DLH-10
		5.6 x 1.9	DLH-30
	Safe-Sided Files	3	
		4.8 x 1.1	DLH-1
		5.5 x 1.7	DLH-3
		4.9x2.1	DLH-7
	File set containing 7 diamond files, one each of DLH-1 through DLH-7		DLH/100
		ning 7 diamond files, , DLH-6, DLH-8, .H-30	DLH/100S

#### DLS DIPRO CONICAL DIAMOND HAND FILES

Shape	Size mm	Item Number Diamond D46	Item Number Diamond D76	Item Number Diamond D107
	4 x 2		DLS-1-D76	
	4 x 3	DLS-2-D46	DLS-2-D76	DLS-2-D107
	6 x 6	DLS-3-D46	DLS-3-D76	DLS-3-D107
	8 x 8	DLS-4-D46	DLS-4-D76	DLS-4-D107

#### DLS DIPRO CONICAL DIAMOND HAND FILES (CONT.)

#### Diamond Files For Diprofil® Filing Machines



Total file length 170 mm

### DLS Set: Set consisting of the above 10 different DLS hand files $\,$



Item Number: DLS/1

#### **DBH DIPRO DIAMOND HAND FILES**

		Fine	Medium	Coarse
Shape	Size mm	Item Number Diamond D46	Item Number Diamond D76	
	6 x 1.5	DBH-1-D46	DBH-1-D76	DBH-1-D126
	Ø3	DBH-2-D46	DBH-2-D76	DBH-2-D126
	5 x 2	DBH-3-D46	DBH-3-D76	DBH-3-D126
	5 x 2	DBH-4-D46	DBH-4-D76	DBH-4-D126
$\triangle$	3.5	DBH-5-D46	DBH-5-D76	DBH-5-D126
<b>O</b>	2.5 x 2.5	DBH-6-D46	DBH-6-D76	DBH-6-D126
	6 x 2	DBH-7-D46	DBH-7-D76	DBH-7-D126
	5.4 x 1.5	DBH-8-D46	DBH-8-D76	DBH-8-D126
	1.7 × 6	DBH-9-D46	DBH-9-D76	DBH-9-D126
	6 x 1.5	DBH-10-D46	DBH-10-D76	DBH-10-D126

#### **DBH DIPRO DIAMOND HAND FILES (CONT.)**

#### Diamond Files For Hand Filing




Total file length approx 140mm Shaft diameter 3mm

### DBH Set: Set consisting of the above 10 different DBH hand files



Item Numbers: DBH-SET-D46, DBH-SET-D76, DBH-SET-D126

#### DLL DIPRO CONICAL DIAMOND HAND FILES



Shape	Size mm	Item Number Diamond D30	Item Number Diamond D46	Item Number Diamond D76
	1.7 x 2	DLL-1-D30	DLL-1-D46	DLL-1-D76
	1.7 x 4	DLL-2-D30	DLL-2-D46	DLL-2-D76
	1.7 x 6	DLL-3-D30	DLL-3-D46	DLL-3-D76
	5 x 2	DLL-4-D30		

## DLL DIPRO CONICAL DIAMOND HAND FILES (CONT.)

Diamond Files For Hand Filing



Total file length approx 140mm Shaft diameter 3mm

DLL Set: Set consisting of the above 10 different DLL hand files



Item Number: DLL-SET

## **DLD DIPRO DIAMOND HAND FILES**

Diamond Files For Hand Filing – Technical Specifications



## DLD DIPRO DIAMOND HAND FILES (CONT.)

Diamond Files For Hand Filing



DLD Set: Set consisting of the above 10 different DLD hand files



Total file length approx 140mm Shaft diameter 3mm Item Number: DLD-SET-D107

## DLX DIPRO DIAMOND HAND FILES SHAPE

Total file length approx 200mm	Shape	Size mm	Item Number Diamond D151
LESC DEAD		11 X 3.5	DLX-1-D151
4510 QHBIQ		Ø5	DLX-2-D151
1814 Oklain		10.5 X 4.4	DLX-3-D151
1510 DRIII	$\triangle$	7.7	DLX-4-D151
C1C		⊿6.3	DLX-5-D151

DLX Set: Set consisting of the above 5 different DLX hand files. Item Number: DLX-SET-D151



\*Grain Sizes according to FEPA

## DLQ DIPRO DIAMOND HAND FILES

Shape	Size mm	Item Number Diamond D126
	8.5 X 1.6	DLQ-1-D126
	Ø4	DLQ-2-D126
	7 x 2.5	DLQ-3-D126
	☑3.5	DLQ-4-D126
$\triangle$	4.5	DLQ-5-D126

Diamond Files For Hand Filing



Total file length approx 200mm Shaft diameter 4mm


DLQ Set: Set consisting of the above 5 different DLQ hand files



Item Number: DLQ-SET-D126

## **Diprofil® Precision Machine Files**


#### **DLM DIPRO CONICAL DIAMOND MACHINE FILES**



Shape	Size mm	Item Number Diamond D46	Item Number Diamond D107
	2.5 x 1.6	DLM-1-D46	DLM-1-D107
	4 x 1.6	DLM-2-D46	DLM-2-D107
	6 x 1.6	DLM-3-D46	DLM-3-D107

Diprofil® Conical Diamond Files For Diprofil® Filing Machines

DLM Set: Set consisting of the 6 different DLM files (as specified above)




Max file length 90mm Max shaft diameter 3mm



Item Number: DLM/1

## DBE DIPRO DIAMOND MACHINE FILES



		Fine	Medium	Coarse
Shape	Size mm	Item Number Diamond D46	Item Number Diamond D76	Item Number Diamond D107
	4 x 2	DBE-1-D46	DBE-1-D76	DBE-1-D107
	Ø3	DBE-2-D46	DBE-2-D76	DBE-2-D107
	5 x 2	DBE-3-D46	DBE-3-D76	DBE-3-D107
	5 x 2	DBE-4-D46	DBE-4-D76	DBE-4-D107
	3.5	DBE-5-D46	DBE-5-D76	DBE-5-D107
0	2.5 x 2.5	DBE-6-D46	DBE-6-D76	DBE-6-D107

Diamond Files For Diprofil® Filing Machines

DBE Set: Set consisting of the above 6 different DBE machine files







Item Numbers: DBE-SET-D46, DBE-SET-D76 DBE-SET-D107

#### **DLB DIPRO DIAMOND MACHINE FILES**


Approx file length 65 mm. Shaft diameter 3 mm.	Shape	Size mm	Item Number Diamond D107
		3.2 X 1.4	DLB-1-D107
		Ø3	DLB-2-D107
		Ø3	DLB-3-D107
	$\triangle$	2.5	DLB-4-D107
		3.2 x 1.4	DLB-5-D107
		4 x 2	DLB-6-D107

DLB Set: Set consisting of the above 6 different DLB machine files. Item Number: DLB-SET-D107

## Diprofil® Precision Steel Files


Steel Files are for use on soft and semi-hardened steel as well as other materials of low and medium hardness.

#### STL 1 - STL 26 PRECISION STEEL FILES



Shape	Size mm	Coarse Cut -00	Fine Cut -1
	5 x 1.5	STL1.00	STL1.1
	Ø3	STL2.00	STL2.1
	5 x 2	STL3.00	STL3.1
	5 x 2	STL4.00	STL4.1
$\triangle$	3.5 x 3.5 x 3.5	STL5.00	STL5.1
	⊠2.5	STL6.00	STL6.1
Set consisting		STL.1/6.00	STL.1/6.1


## STL 1 - STL 26 PRECISION STEEL FILES (CONT.) AND STL 101 PRECISION STEEL FILES



Shape	Size mm	Coarse Cut -00	Fine Cut -1
	3.3 x 1	STL21.00	STL21.1
	Ø2	STL22.00	STL22.1
	3.2 x 1.1	STL23.00	STL23.1
	3 x 1.3	STL24.00	STL24.1
$\triangle$	2.2 x 2.2 x 2.2	STL25.00	STL25.1
	☑1.7	STL26.00	STL26.1
Set consisting STL-1 to STL-6		STL.21/26.00	STL.21/26.1



Shape	Size mm	Coarse Cut -00	Fine Cut -1
	4 x 2	STL11.00	STL11.1
	Ø3	STL12.00	STL12.1
	4.7 x 2.5	STL13.00	STL13.1
	<b>Ø</b> 3	STL14.00	STL14.1
Set consisting STL-1 to STL-6		STL.11/16.00	STL.11/16.1



Shape	Size mm	Coarse Cut -00	Fine Cut -1
	10 x 2.5	STL101.00	STL101.1
		STL1A.00	STL1A.1



# MINIMO® FINISHING SYSTEMS

## Minimo® One Series

#### THE MINIMO® ONE

The Minimo® One Series hand finishing system is designed to provide unsurpassed accuracy, reliability, power and versatility, while being comfortable and natural to use with minimum fatigue. An innovative hand switch, built right into the handpiece itself, is just one of many new features that makes Minimo® the most advanced and easy to use handpiece on the market.

Plus, when you use the Minimo® One system in conjunction with DiaMold® diamond compounds, lubricants and the full range of toolroom products from Engis®, you can be assured of high precision results, time and time again (Section 1 of this catalog contains a full description of our diamond compounds and lubricants.)

- A Collets can be changed easily using a V wrench.
- B Minimo® rotary heads utilize a simple tool changing mechanism that does not require wrenches or keys. Tools can be easily changed out by a quick turn of the collet release ring. This facilitates the use of polishing tools with different shank diameters by simply switching out the collets.
- C The Minimo® polishing system offers maximum flexibility with a wide range of both heads and motor assemblies. By optimizing the head and motor assembly combination for each application, you have the perfect tool for every job. The head can be mounted to a motor in a snap.
- D In addition to the On/Off switch on the power supply, each motor is supplied with its own On/Off switch. This allows the operator to stop and start the handpiece quickly, even when working out of reach of the power supply. The switch is inset in the tool to minimize the risk of accidentally starting the motor.
- E Removable Curled Power Cord



## EASY EXCHANGE OF COLLETS (A)





## EASY EXCHANGE OF TOOLS (B)





## VERSATILITY OF HANDPIECES (C)



## HAND SWITCH FOR MAXIMUM CONTROL (D)





Motor Model & Maximum Speed (x 1,000)



# **TOOLS**

## Minimo® One

#### THE MINIMO® ONE HANDPIECES & HEAD ATTACHMENTS

Adding to the Minimo® One's versatility is a complete array of attachments, including heads, clamp heads and gear reduction units for more power.

Versatility of Handpieces: Minimo® One Rotary Handpieces consist of a combination of various heads and motor assemblies of different specifications. Different combinations of heads, motor assemblies and other attachments can customize the tool for different applications. Heads can be mounted to motors in a snap.

Variety of Handpieces: Engis® offers a full selection of handpieces, ranging from Standard, Slender and Heavy Duty Rotary units to POLYTOR Ultrasonic systems – the ideal solution for removing EDM scale.









Polytor Ultrasonic Handpiece

Standard Rotary Straight Head Handpiece

Rubron Lateral Swing Handpiece







Mini-Belt Sander



Recipron Reciprocating Handpiece



## MINIMO® ONE SERIES - TABLE OF CONTENTS

Product	Page
Power Packs	45
Polytor Ultrasonic Systems	46
Standard Rotary Handpieces	47
Slender Rotary Handpieces	50
Heavy Duty Rotary Handpieces	51
Rubron System	54
Anglon Systems & Tools	55
Recipron	63
Mini-Belt Sander	64
Motors	66
Heads	67
Accessories	70

## Minimo® Power Packs

#### C2112 DC Power Pack (Replaces C311 & C111)

2 Standard Handpiece Stations 60 VA Input Voltage: C115V  $\pm$  5% (50/60 Hz) Output Voltage: DC 1-30 V AC 144mm (W)  $\times$  218mm (D)  $\times$  116mm (H) 5.5 lbs (2.5kg)



## P30 Polytor Power Pack (Replaces P211 and P111)

1 Ultrasonic Handpiece Station 30 VA Input Voltage: AC100~AC240V (50/60Hz) Output Voltage: See Below 144mm (W) X 221mm (D) X 116mm (H) Approx. 1.3kg



#### Features:

- This high-end power pack includes new functions for maximizing the performance of Minitor handpieces.
- The C2112 power pack identifies the type of handpieces which are connected indicates rotation speed and controls optimum torque.
- Also compatible with the earlier handpieces which do not have the motor identification chip.
- Convenient digital display of output rate (%).
- Includes RM11 Rubber Cradle, CA11 Power Cord, and PFU-2.0A Fuse

#### Features:

- The P30 is equipped with a feedback feature to detect overloading.
- Features an audible beep that lets you know when the handpiece is turned ON/OFF or when the tool is overloaded. This feature allows the handpiece to perform to its full capability without damaging itself or the power pack.
- Output Voltage: 27W max. (STROKE CONTROL, Power Mode on), 18W max. (STROKE CONTROL, Power Mode off), and 18W max. (VOLTAGE CONTROL)
- Includes RM11 Rubber Cradle.
- CA11(115V) power cord and US21 Ultrasonic handpiece are sold separately.

#### PRODUCT DETAILS

- Handpiece identification function: When the Ver. 2
  handpiece is connected, the power pack identifies its
  motor type, indicates its rotation speed and controls
  optimum torque.
- Digital display: Identifies a connected handpiece type, the power pack automatically selects its display type (rotation speed (x1000 min) or output rate (rate %)).
- Error code display function: Errors of power pack or handpiece are indicated as error code on the display
- Microcomputer control: The high-end microcomputer control identifies the connected handpiece type and manages its optimum output
- Rotation direction switch: Allows the user to change the rotation direction of handpiece (forward or reverse).

- LED load meter: Loaded condition in operation is displayed on LED meter. Error is alerted by LED meter and sound when overloading.
- External I/O signal control function is standard: Input/output signals are available from the foot switch socket located on the back of the power pack.
- Foot switch holding function (when using V301 foot switch): Rotation speed set by the variable foot switch can be maintained by pressing the hand switch.
- NEW BRAKING SYSTEM: Quick braking system stops the handpiece immediately. In addition, the system can quickly change rotation speed shifting from high to low speed.

## Minimo® Polytor Ultrasonic

#### **US21 POLYTOR (ULTRASONIC)**

The POLYTOR handpiece (US21) is indispensable for mold finishing, providing powerful and stable ultrasonic vibration.

The US21 is great for small and intricate work especially in slots and ribs where hand work is difficult. Because the reciprocation is short and moves with ultrasonic speed, the tool tip can be used in corners, wall ends and for fine detail work.

Since the frequency is adjusted automatically, operation of the US21 is simple and easy. Because of the tool's aggressive cutting action, processing time is reduced dramatically, saving 70 to 75% of finishing time while improving quality. A large variety of tools for use with the US21 are available for cleaning up milled and EDM surfaces to mirror polishes.

#### **POLYTOR HANDPIECE US21**



#### **FEATURES & BENEFITS**

- Removing EDM scale
- Convenient for pattern cutting of printed circuit boards
- Ideal for deburring, grinding, cutting, polishing and honing
- · Finishing precious metals and jewels

The Hand Switch enables the tool to be switched ON/OFF on the handpiece side as well; this offers maximum convenience when work requires frequent switching ON/OFF or when working out of reach of the Power Pack. This adoption of the new mechanism improves the switch durability as well.

#### **FEATURES & BENEFITS**

- · Compact and lightweight
- Built-in ON/OFF SWITCH
- Removable curled power cord makes storage convenient
- Employs an advanced high performance oscillating unit
- Compatible with P30 Power Pack

### STANDARD TOOLS (1PC EACH)

- SA8103 Holder with SA4102 Diamond File
- SA8151 Holder with SA5005 Ceramic Stone

Toolho	older Selection for Polytor U	Itrasonic
SA8101	d = Ø1mm	17
SA8102	d = Ø2mm	
SA8103	d = Ø3mm	d M6
SA8104	d = Ø4mm	
SA8151	t = 1mm	18
SA8152	t = 2mm	
SA8153	t = 3mm	t M6
SA8154	t = 4m	
SA8181	t = 0.5mm	17
SA8182	t = 1mm	t #

## Minimo® Standard Rotary Handpieces

#### STANDARD ROTARY HANDPIECES

The Minimo® One Handpieces are designed to provide the user with unsurpassed versatility with its quick-change H011/E Standard Head options. Minimo heads and motors have matching threads which make changing a straight tool to a 90 degree tool a very simple process. Tool change is a 1/4 turn process without the need of a special wrench or spanners.


Each motor has an On/Off switch on its side for one-hand operation. 3/32" and 1/8" collets are standard with each handpiece. Seven other collets sizes are available and sold separately.



Minimo® One Handpieces are used with C2112 Power Pack

## STANDARD ROTARY SPECIFICATIONS

	V112H	M212H	M112H	V212H
Speed	Ultra-high speed	High speed	High speed	High speed
Motor Model	KV112H	KM21H	KM112H	KV212H
Head Model	H011/E	H011/E	H011/E	H011/E
Hand Switch Color	Ivory	Red	Violet	Pink
Speed Range RPM	2,000–50,000	3,000–30,000	3,500–35,000	2,000–40,000
Input Voltage (D.C.V.)	3–30	3–30	3–30	3–30
No-load Current (D.C.A.)	0.45	0.40	0.35	0.40
Maximum Torque (cN.M)	2.3	2.8	3.4	2.7
Weight (g) [not including cord]	204	290	232	240
		Dimensions (mm)		
L	147	167	160	149
L1	76	96	89	78
L2	71	71	71	71
D	Ø29	Ø33	Ø29	Ø33
D1	Ø26.4	Ø30.4	Ø26.4	Ø30.4
D2	Ø14.5	Ø14.5	Ø14.5	Ø14.5



## STANDARD ROTARY SPECIFICATIONS (CONT.)

	M212	M112	V212H	M112G
Speed	Medium speed	Medium speed	Medium speed	Geared low speed
Motor Model	KM21	KM11	KV21	KM11G
Head Model	H011/E	H011/E	H011/E	H011/E
Hand Switch Color	Green	Blue	Orange	Yellow
Speed Range RPM	1,500–15,000	2,000–20,000	2,500–25,000	660–6,600
Input Voltage (D.C.V.)	3–30	3–30	3–30	3–30
No-load Current (D.C.A.)	0.30	0.30	0.40	0.34
Maximum Torque (cN.M)	5.9	4.5	3.9	9.8
Weight (g) [not including cord]	290	232	240	273
		Dimensions (mm)		
L	167	160	149	176
L1	96	89	78	105
L2	71	71	71	71
D	Ø33	Ø29	Ø33	Ø29
D1	Ø30.4	Ø26.4	Ø30.4	Ø26.4
D2	Ø14.5	Ø14.5	Ø14.5	Ø14.5

## **COLLET SELECTION TABLE (STANDARD ROTARY)**



Code	KP-050	KP-051	KP-007	KP-005	KP-052	KP-031	KP-036	KP-032	KP-033
	(mm)	(mm)	(mm)						
Inside Diameter (mm)	Ø1.0	Ø1.2	Ø1.4	Ø1.6	Ø1.8	Ø2.0	Ø2.34 (3/32")	Ø3.0	Ø3.175 (1/8")

## Minimo® Slender Rotary Handpieces

#### **SLENDER ROTARY HANDPIECES**

These are small and lightweight handpieces with precision balanced motors for vibration-free operation – very comfortable to hold and use for very long periods of time.

3/32" and 1/8" collets are standard with each handpiece. Seven other collets size are available and sold separately.




#### **SLENDER ROTARY SPECIFICATIONS**

	V112HS	M112HS	M112S
Speed	Ultra-high speed	High speed	Medium speed
Motor Model	KV11H	KM21H	KV11
Head Model	H021/E	H021/E	H021/E
Hand Switch Color	Ivory	Pink	Blue
Input Voltage (D.C.V.)	3–30	3–30	3–30
No-load Current (D.C.A.)	0.45	0.40	0.30
Maximum Torque (cN.M)	2.3	2.7	4.5
Weight (g) [not including cord]	192	228	222

#### STANDARD ROTARY SPECIFICATIONS (CONT.)

Dimensions (mm)					
L	145	158	147	158	
L1	76	89	78	89	
L2	69	69	69	69	
D	Ø29	Ø29	Ø33	Ø29	
D1	Ø26.4	Ø26.4	Ø30.4	Ø26.4	
D2	Ø10.8	Ø10.8	Ø10.8	Ø10.8	



## Minimo ® Heavy-Duty Rotary Handpieces

## **HEAVY DUTY HANDPIECES**

The Minimo \*Heavy Duty Handpiece Series is designed with a reinforced housing. It accepts shank sizes up to 6.35mm for heavy cuts and provides unsurpassed versatility with its quick-change head options. Minimo \*heads and motors have matching threads which makes changing a straight tool to a 90 degree tool a very simple process without the need of a special wrench or spanners. Each motor has an on/off switch on its side for one-hand operation.

## M212HD HIGH SPEED HANDPIECE

Offers a robust reinforced head housing for added strength and easy grip. Accepts larger shank diameter tooling up to 1/4" diameter. Head is easily removed from its screw mount and replaced with other optional heads. Used with C2112 Power Pack.

## TECHNICAL DATA

• Standard Rotary

Call us at 847/808-9400

- Standard Collets: 1/8" & 1/4"
- Speed Range: 3,000-30,000 RPM



Head: H031/E Motor: KM 21H/ 3,000-30,000 RPM

## M212D MEDIUM SPEED HANDPIECE

The lower RPM of this tool offers a higher torque load ratio than the faster RPM model shown on previous page. Can be used with all listed power packs.

## **TECHNICAL DATA**

· Standard Rotary

• Standard Collets: 1/8" & 1/4"

• Speed Range: 1,500-15,000 RPM




Head: H031/E Motor: KM 21/1,500-15,000 RPM

#### **HEAVY DUTY ROTARY SPECIFICATIONS**

	M212HD	M212D
Speed	High speed	Medium speed
Motor Model	KM212H	KM212
Head Model	H031/E	H031/E
Hand Switch Color	Red	Green
Speed Range RPM	3,000–30,000	1,500–15,000
Input Voltage (D.C.V.)	3–30	3–30
No-load Current (D.C.A.)	0.40	0.30
Maximum Torque (cN.M)	4.2	5.9
Weight (g) [not including cord]	350	351
	Dimensions (mm)	
L	177	177
L1	96	96
L2	81	81
D	Ø33	Ø33
D1	Ø30.4	Ø30.4
D2	Ø20	Ø20

## SPEED/ TORQUE CURVE (DATA FOR DIFFERENT MOTOR MODELS)



## **COLLECT SELECTION TABLE (HEAVY DUTY ROTARY)**



Code	KP-061 (mm)	KP-062 (mm)	KP-063 (mm)	KP-066 (mm)	KP-067 (mm)	KP-060 (mm)	KP-064 (mm)
Inside Diameter (mm)	Ø2.34 (3/32")	Ø3.0	Ø3.175 (1/8")	Ø4.0	Ø5.0	Ø6.0	Ø6.35 (1/4")

## Minimo® Rubron System

#### **M212LRV RUBRON SYSTEM**


The Rubron is a unique handpiece with lateral (side-to-side) movement adjustable up to 1.6mm, ideal for finishing narrow slots and grooves, plus deep recesses where precise control is needed.

The Rubron has a tapered toolholder nose to aid in getting into those hard-to-reach areas.

The V-shaped tool holder chuck mounts shank sizes from 1.5 to 4.7mm shafts.

The motor has a built-in ON/OFF switch for easy one-hand operation and is powered by the C2112 Power Pack.






Examples of applications

#### **RUBRON SPECIFICATIONS**

	M212LRV
Frequency (times/min)	800 – 8,000
Head Amplitude (mm)	0–1.6
Tool Shank Diameters (mm)	1.5–4.7
Input Voltage (D.C.V.)	3–30
No-load Current (D.C.A.)	0.25
Maximum Torque (cN-M)	6.9
Hand Switch Color	Black
Weight (g)	300

## SPEED/ TORQUE CURVE



Note: The amplitude depends on the length of the tool used.

## Minimo® Anglon Systems

#### **ANGLON SYSTEM**

Anglon tools are offered with heavy duty 90° or 120° angled head designs suitable for grinding and polishing of both flat and curved surfaces, especially on those hard-to-reach internal surfaces.

Each tool features a built-in ON/OFF switch, two standard collets (3/32" & 1/8") and a quick and easy tool changing mechanism - no wrenches are required!

Anglon tools offer quick and easy tool exchange - simply turn the collet release ring to lock or remove the tool.





#### M112GRAD LOW SPEED TOOL WITH 90° ANGLE HEAD

## **TECHNICAL DATA**

Standard Collets: 1/8" & 3/32"Speed Range: 620 - 6,200 RPM

· High torque

Used with C2112 Power Pack



Motor: KM11G

#### M212RAD MEDIUM SPEED TOOL WITH 90° ANGLE HEAD

#### TECHNICAL DATA

Standard Collets: 1/8" & 3/32"Speed Range: 1,420 - 14,200 RPM

• Used with C2112 Power Pack



Head: H221/E Motor: KM11G

## M112GA LOW SPEED TOOL WITH 120° ANGLE HEAD

#### **TECHNICAL DATA**

Standard Collets: 1/8" & 3/32"Speed Range: 630 - 6,300 RPM

History and the second

· High torque

• Used with C2112 Power Pack



Head: H231/E Motor: KM11G

## M212A MEDIUM SPEED TOOL WITH 120° ANGLE HEAD

## TECHNICAL DATA

Standard Collets: 1/8" & 3/32"Speed Range: 1,440 - 14,400 RPM


• Used with C2112 Power Pack



Head: Head: H231/E Motor: KM21

## **ANGLON SPECIFICATIONS**

	M112GRAD	M212RAD	M112GA	M212A
Speed	Low speed high torque	Medium speed	Low speed high torque	Medium speed
Motor Model	KM11G	KM21	KM11G	KM21
Head Model	H221/E	H221/E	H231/E	H231/E
Hand Switch Color	Yellow	Green	Yellow	Green
Speed Range RPM	620–6,200	1,420–14,200	630–6,300	1,440–14,400
Input Voltage (D.C.V.)	3–30	3–30	3–30	3–30
No-load Current (D.C.A.)	0.35	.40	0.35	0.40
Maximum Torque (cN.M)	9.8	5.9	9.8	5.9
Weight (g) [not including cord]	368	387	351	395
		Dimensions (mm)		
L	167	158	183	174
L1	105	96	105	96
L2	62	62	78	78
D	Ø29	Ø33	Ø29	Ø33
D1	Ø26.4	Ø30.4	Ø26.4	Ø30.4
Н	47.5	47.5	47.5	47.5




## **COLLET SELECTION TABLE (ANGLON TOOLS)**



Code	KP-050	KP-051	KP-007	KP-005	KP-052	KP-031	KP-036	KP-032	KP-033
	(mm)	(mm)	(mm)						
Inside Diameter (mm)	Ø1.0	Ø1.2	Ø1.4	Ø1.6	Ø1.8	Ø2.0	Ø2.34 (3/32")	Ø3.0	Ø3.175 (1/8")

## SPEED/TORQUE CURVE (DATA FOR DIFFERENT MOTOR MODELS)



## TOOLS FOR ANGLE ROTARY HANDPIECES (5 PER BOX)

Soft rubber pads are available in 4 different diameters ( $\emptyset$ 10 mm,  $\emptyset$ 20 mm,  $\emptyset$ 30 mm and  $\emptyset$ 40 mm).


Pressure sensitive adhesive (PSA) backing enables you to replace discs in a snap. The backing also serves as a cushion to enable softer contact with work pieces.

Sandpaper discs resist spalling and loading with aggressive cutting action.

Zirconia discs utilize tough zirconia alumina abrasives developed especially for hard-to-cut materials.



#### ABRASIVE DISC & POLISHING DISC HOLDERS (20 PER BOX)




Shank = Ø3.0mm (All Holders)

#### SOFT RUBBER PADS (20 PER BOX)

These rubber pads mount to the disc holder with PSA backing. The disc face has a Velco-type surface used to mount the PSA-backed disc above (SA3001, SA3002, SA3003).


#### Eye protection recommended.



## SANDPAPER DISC WITH PSA BACKING (100 PER BOX)

These flexible discs are made of aluminum oxide resin bonded for great durability. The pressure sensitive adhesive (PSA) backing can withstand the heat generated by high friction. PSA discs will hold until removed by hand. There is a peel-off backing on each disc to maintain adhesive freshness.

#### Eye protection recommended




## SANDPAPER DISC WITH PSA BACKING (100 PER BOX) (CONT.)

		(12,000)		40
Grit Size	11.	21	31	ii
#60	SA2111	SA2131	SA2151	SA2171
#80	SA2112	SA2132	SA2152	SA2172
#120	SA2113	SA2133	SA2153	SA2173
#180	SA2114	SA2134	SA2154	SA2174
#240	SA2115	SA2135	SA2155	SA2175
#320	SA2116	SA2136	SA2156	SA2176
#400	SA2117	SA2137	SA2157	SA2177
#600	SA2118	SA2138	SA2158	SA2178
#800	SA2119	SA2139	SA2159	SA2179
#100	SA2120	SA2140	SA2160	SA2180

#### ZIRCONIA DISC WITH PSA BACKING (100 PER BOX)

These Zirconia discs are used on hard-to-grind materials. Fast and clean cutting, they are available in 4 grit sizes and supplied with PSA backing.


## Eye protection recommended.



#### METAL-BASED DIAMOND DISC WITH PSA BACKING (1 PER BOX)

These metal-based diamond discs are thin metal discs plated with diamond grains. Suitable for various materials such as sintered hard alloy, ceramics, glass, etc. Also supplied with PSA backing.


#### Eye protection recommended



#### CLOTH-BASED DIAMOND DISC WITH PSA BACKING (3 PER BOX)


These cloth-based diamond discs are soft cloth discs plated with diamond grains. Suitable for sintered hard alloy, ceramics and glass.

#### Eye protection recommended



#### **RUBBER DISC WITH PSA BACKING (20 PER BOX)**


**WA Disc-formed abrasive rubber.** These rubber discs are made of high elastic rubber which resists scratching and produces a uniform finish.



## FELT DISC WITH PSA BACKING (20 PER BOX)


Thickness 2 mm. These felt discs are compressed dense structures of carefully selected fine quality wool.

These discs should be used with a DiaMold® diamond polishing compound and Hyprelube® lubricant (see Section 1). Rich in elasticity, they fit well in curved surfaces and are applicable to finish polishing.




## GREEN FELT DISC WITH PSA BACKING (20 PER BOX)

Compound impregnated. Thickness 2 mm. These green felt discs are compressed dense structure of carefully selected fine quality wool impregnated with chromium oxide polishing compound. They are directly applicable to finish polishing, precision polishing and glossing, and require no polishing compounds.



#### FELT DISC WITH SOFT CUSHION WITH PSA BACKING (20 PER BOX)

These felt discs have a soft cushion inserted between the contact surface and felt disc so that they fit well in curved surfaces and enable impact-free polishing.




#### CUSHION DISC NON-WOVEN CLOTH IMPREGNATED WITH POLISHING COMPOUNDS WITH PSA BACKING (20 PER BOX)

These cushion discs have high elasticity and fit well with work pieces. Resultant surfaces are smooth and free of irregularities. They also produce minimal debris and resist clogging, even with fine grains.

Elastic, pliable rubber discs are fit to polish flat and curved surfaces. These are extremely durable.

#### Eye protection recommended



## Minimo® Recipron Systems

#### RE112, RE212

The Recipron handpiece generates a reciprocating stroke, ideal for filing, lapping, stoning, polishing and scraping operations. Comfortable hand fitting pistol grip with built-in ON/OFF SWITCH provides greater processing accuracy. Smooth operation, vibration free. Eliminates operation fatigue.

#### **RE112**:

- Stroke range: 0 8 mm
- Stroke speed: 260 3,500 times/min.
- Stroke-oriented type

#### **RE212:**

- Stroke speed: 460 7,000 times/min.


POWER PACK: Used with C2112 Power Pack.


#### **FEATURES & BENEFITS**


- · Slim and smooth body shape allows moreaccurate processing.
- · 2 modes of the tool holder action. When the spindle securing knob is released, the toolholder will rotate freely, ensuring tools to fit the surface of the workpiece.
- · Built-in ON/OFF SWITCH.
- 2 models to choose from.

The Hand Switch is standard equipment on the pistol-shaped handpiece. To ensure manipulations by the fingertip only, the switch is recessed at a position on the grip where you can easily use it.

## Examples of applications below:










- (Speed model) Stroke range: 0 2 mm
- · Speed-oriented type

#### **RECIPRON SPECIFICATIONS**

	RE112	RE212
Stroke (m/min)	0–8	0–2
Speed Range (times/min)	260–3,500	460–7,000
Input Voltage (D. C. V.)	3–30	3–30
No-load Current (D. C. A.)	0.3	0.35
Diameter of Mountable Shafts (mm)	2.0–6.35	2.0–6.35
Carbon Brush	KE-580	KE-580
Weight (g)	790	783



**Dimensions** 

## Minimo® Mini-Belt Sander

#### BS312

A handy type belt sander, equipped with ON/OFF SWITCH, that excels in deburring, grinding and polishing.

POWER PACK: Used with C2112 Power Pack.

The main body is equipped with the belt arm H82 as standard; belts with a width of 6 or 8 mm can be used.




#### **FEATURES & BENEFITS**

- Flexibly addresses machining of small parts and objects of complicated shapes.
- A large variety of sanding belts are available that are suitable for various materials including metals, ceramics, stone and wood.
- · Quick and easy exchange of belts.
- Optional belt arms are available, which allow you to extend the scope of applications.
- Built-in ON/OFF SWITCH.
- Removable curled power cord makes storage convenient.


## **BS312 (CONT.)**

## Examples of applications below:










#### MINI BELT SANDER SPECIFICATIONS

	BS312
No-load Belt Speed (m/min)	49 - 2,700
Input Voltage (D.C.V.)	3–30
No-load Current (D.C.A.)	0.3
Carbon Brush	KE-580
Weight (g)	440



## ABRASIVE BELT FOR THE MINI BELT SANDER (CIRCUMFERENCE: 300MM)



## **BELT ARM**







H82 Standard belt arm (applicable belt width: 6 and 8 mm)

H81 Thin belt arm (applicable belt width: 4 and 6 mm)

## Minimo<sup>®</sup> Motors

Ranging from ultra-high speed to the low speed geared type, nine types of micromotors, each with distinctive features, are available in the product line.

The motor and the head can each be purchased separately, or as a complete unit.

#### **KV112H ULTRA-HIGH SPEED MOTOR**

#### **TECHNICAL DATA**

• Speed Range: 2,000-50,000 RPM

Torque: 2.3 cN-MCarbon brush: KE-605Hand Switch Color: Ivory



#### KM112H HIGH SPEED MOTOR

#### **TECHNICAL DATA**

• Speed Range: 1,000-35,000 RPM

Torque: 3.4 cN-MCarbon brush: KE-575Hand Switch Color: Violet



#### **KM212H HIGH SPEED MOTOR**

## **TECHNICAL DATA**

• Speed Range: 1,000-30,000 RPM

Torque: 4.2 cN-MCarbon brush: KE-580Hand Switch Color: Red



## KM112 MEDIUM SPEED MOTOR

## **TECHNICAL DATA**

• Speed Range: 1,000-20,000 RPM

Torque: 4.5 cN-MCarbon brush: KE-575Hand Switch Color: Blue



#### **KM212 MEDIUM SPEED MOTOR**

## TECHNICAL DATA

• Speed Range: 1,000-15,000 RPM

Torque: 5.9 cN-MCarbon brush: KE-580Hand Switch Color: Green



#### **KM212L LOW SPEED MOTOR**

## TECHNICAL DATA

• Speed Range: 800-8,000 RPM

Torque: 6.9 cN-MCarbon brush: KE-580Hand Switch Color: Black



#### KM112G LOW SPEED GEAR-TYPE MOTOR

#### **TECHNICAL DATA**

• Speed Range: 660-6,600 RPM

Torque: 9.8 cN-MCarbon brush: KE-575Hand Switch Color: Yellow



## Minimo® Heads

Minimo offers the most complete line of heads for a wide range of applications. Grinding, deburring, drilling, lapping and polishing can be performed using a combination of these heads and motors. The heads and motors are attached in a snap.

## H011/E

Standard Head: The most universal head. Standard collets 3/32"(KP-036) and 1/8" (KP-033)



## H021/E

**Slender Head:** Slim & lightweight - suitable for delicate processing work. Standard collets 3/32"(KP-036) and 1/8" (KP-033)



#### H031/E

**Heavy-Duty Head:** Standard collets 1/8" (KP-063) and 1/4" (KP-064)



**Long Slender Head:** Ideal for hard to reach areas with reach size 1/2" x 3-7/8". Standard collets 3/32"(KP-036) and 1/8" (KP-033)



#### H051/E

**Air Head:** Produces a jet of air around the tool to blow shavings and dust off work area. Standard collets 1/8" (KP-063) and 1/4" (KP-064)



#### HANDPIECE CROSS REFERENCE FOR MOTORS AND HEADS

Head Selection	Motor Selection								
HO11/E	KV112H		KM112H	KM212H		KM112	KM212	KM212L	KM112G
HO21/E	KV112H		KM112H	KM212H		KM112	KM212	KM212L	KM112G
HO31/E	KM212H		KM212L	KM112G					
HO41/E		KM112H	KM212H		KM112	KM212	KM212L	KM112G	
HO51/E	KV112H		KM112H						
H221/E	KM212	KM212L	KM112G						
H231/E	KM212	KM212L	KM112G						
H311	KM212L	KM112G							

### H221/E

#### **TECHNICAL DATA**

- Heavy-Duty Anglon Head 90°
- Maximum speed 15,000 RPM
- Standard Collets 3/32" (KP-036) and 1/8" (KP-033)



## H231/E

## TECHNICAL DATA

- Heavy Duty Anglon Head 120°
- Maximum speed 15,000 RPM
- Standard Collets 3/32" (KP-036) and 1/8" (KP-033)



# H311


## TECHNICAL DATA

- Rubron Head (Adjustable swing up to 1.6 mm at chuck edge)
- Maximum speed 8,000 RPM




## **COLLET SELECTION TABLE**

Head Model
HO11/E
HO21/E
HO41/E
HO51/E
HO51P/E
H221/E
H231/E
11231/2




HO31/E



69

H211/E





# **ACCESSORIES**

## Minimo® Accessories - Power Cords

#### FOOT SWITCH (CAN BE USED WITH ALL POWER PACKS)

## FS201

FS211

## VC301



#### Features:

- An ON/OFF type foot switch.
- When pressed, the handpiece is on. When released, the handpiece will stop.
- Cord length: 1.5 m / 4'6"

## Features:

- 2-mode changeover type.
- · You can perform ON/OFF switching either in mode A or B.
- Cord length: 1.5 m / 4'6"
- A-mode: Once you step on the foot switch, the ON state continues even if you take your foot off the switch; step on it for a second time, and it changes into the OFF state. •
- B-mode: When pressed the hand piece is on, when released, the handpiece will stop.

## Features:

- In addition to ON/OFF switching, the speed and power control for the POLYTOR handpiece action is provided depending on how far the pedal is depressed.
- Cord length: 1.5 m / 4'6"

#### POWER CORD FOR HANDPIECE

Cords for the D.C. motor handpiece (with a 3-pin connector)

## **CURLED CORD - CC711**



## **TECHNICAL DATA**

- Length: 1.5 m / 4'6"
- · Power cord for the D.C. motor handpiece
- · Standard accessory with the handpiece



#### **CURLED CORD - CC811 - 4 PIN CONNECTOR**

## TECHNICAL DATA

- Length: 1.5 m / 4'6"
- Power cord for the POLYTOR US21 ultrasonic handpiece
- Standard accessory with POLYTOR ultrasonic handpiece



#### **EXTENSION CORD - CB211**



## **TECHNICAL DATA**

- Length: 3 m / 9'6"
- Straight extension cord for connecting the POWER PACK and the curled cord (CC711).
- Two or more extension cords can be connected.



## **EXTENSION CORD - CB311 - 4 PIN CONNECTOR**



## **TECHNICAL DATA**

- Length: 3 m / 9'6"
- Straight extension cord for connecting the POWER PACK and the curled cord (CC811).
- Two or more extension cords can be connected.



## POWER CORD FOR POWER PACK

Standard accessory with the POWER PACK

#### **CA10**



## TECHNICAL DATA

- · Length: 2 m / 6'6"
- Power cord for all Minimo Power Packs (AC115V)



### Minimo® Accessories - Tool Cases

**Aluminum-made Carrying Cases:** Conveniently portable, the robust aluminum carrying case houses the POWER PACK, handpieces and other accessories neatly and safely, with a padded interior.

### **BX01 CARRYING CASE (SMALL)**

### TECHNICAL DATA

- Outside dimensions: 365 (W) x 210 (D) x 280 (H) mm
- · Weight: 2.6kg



### **BX02 CARRYING CASE (LARGE)**

### **TECHNICAL DATA**

- Outside dimensions: 470 (W) x 230 (D) x 340 (H) mm
- · Weight: 4.2kg





### Minimo® Tool Stand/Rubber Cradle

### **RUBBER CRADLE - RM11**

Provides a safe and convenient resting place for your handpiece when not in use. Helps prevent handpiece damage from accidental drop.

- · Cradle made of rubber
- Can be used for all listed handpieces
- Outside dimensions: 72 (W) x 72 (D) x 30 (H) mm



### **SPHERICAL VISE - V151**

This 18.5 lb steel sphere mounted on a rubber base securely holds smaller parts during stoning and polishing operations. No need to clamp this vise to the bench.

- V-shaped grooves on the mouth ensure an even grasp of the workpiece
- Detachable adjusting handle

### **Spherical Base Specifications**

Sphere Diameter	130 mm / 5.118"
Height	65 mm / 2.559"
Base Width	60 mm / 2.362"
Max Mouth Width	62 mm / 2.440"
Sphere Depth	50 mm / 1.968"
Clamping Capacity	44.5 mm / 1.75"
Weight	8.5 kg / 18.75 lbs





## ROTARY FINISHING TOOLS

### **Rotary Finishing Tools**

### DIAMOLD® MOUNTED WOOL FELT BOBS (1 PER BOX)

Mandrel Mounted: DiaMold® Felt Bobs are made of pure wool in a broad variety of sizes, shapes and degrees of hardness for any finishing requirement. The mandrels are exactly centered for true-running operation. When ordering, specify part number and hardness desired.

#### Standard Shapes in Medium, Hard:

Part No.	Width	Depth	Shank
503.MS.1A	1/2"	1"	1/8"
503.MS.1C	1"	2"	1/4"
503.MS.2A	1/2"	1/2"	1/8"
503.MS.3C	3/8"	1/2"	1/8"
503.MS.3F	1/2"	1"	1/8"
503.MS.4B	1/2"	3/4"	1/8"
503.MS.5A	1/2"	3/4"	1/8"
503.MS.6A	1/2"	1/2"	1/8"

### Cylinders - Medium, Hard, Rock Hard

Part No.	Width	Depth	Shank
503.CB.2	1/4"	1/4"	1/8"
503.CB.2A	3/8"	3/8"	1/8"
503.CB.3	3/8"	1/2"	1/8"
503.CB.4	1/2"	1/2"	1/8"
503.CB.5	1/2"	3/4"	1/8"
503.CB.6	1/2"	1"	1/8"
503.CB.7	3/4"	3/4"	1/8"
503.CB.10	1"	1"	1/4"

### **Ordering Example:**

Prefix: 503. P/N: MS.1A. Hardness: M\*

\*M = Medium H = Hard RH = Rock Hard

### Felt Reciprocating Bob:



LSB.2.MED 3/8" x 3/8" x 1-1/2"



Max. RPM 15,000

### **DIAMOLD® FELT BOB ASSORTMENT 503.40**

This assortment includes the following:

12 cylinders: 2 each of 4 sizes in each hardness: Medium,

Hard, Rock Hard; all 1/8" mandrel

Sizes: CB-2 1/4" x 1/4", CB-3 3/8" x 1/2", CB-4 1/2" x

1/2", CB-7 3/4" x 3/4"

8 standard shapes: 1 each of 4 sizes in Medium & Hard all 1/8" mandrel, 1/2" diameter - MS1A 1/2"  $\times$  1", MS2A 1/2"  $\times$  1/2",

MS3F 1/2" x 1", MS6A 1/2" x 1/2" **6 Felt Finger Pads:** 1" x 3" - 1/8" thick

### Eye protection recommended






### DIAMOLD® WOOD BOBS (1 PER BOX)

DiaMold® Bobs are available in Hydulignum, a highly-compressed hard wood laminated in layers with plastic.

The grain direction is perpendicular to the circumference to assure uniform lapping surface and efficient charging. They are recommended for fast stock removal or where exact contour or shaping is required - use 15 micron or coarser Engis® Diamond Compounds for these applications. Bobs are also available in selected soft pine for pre-finish before final felt polishing. Diamond Compounds grade of 15 micron or finer are recommended for use with these bobs.





**1/8" Mandrel Mounted Cones and Cylinders:** HYD-1/SFT-1, HYD-2/SFT-2, HYD-3/SFT-3, HYD-4/SFT-4 HYD-5/SFT-5, HYD-6/SFT-6


Hydulignum (Hard Wood)	Pine (Soft Wood)	Size	Shape
501.HYD.1	501.SFT.1	3/4" x 1-3/16"	Cone
501.HYD.2	501.SFT.2	7/16" x 1-3/16"	Cone
501.HYD.3	501.SFT.3	9/32" x 5/8"	Cone
501.HYD.4	501.SFT.4	3/4" x 1-1/8"	Cylinder
501.HYD.5	501.SFT.5	7/16" x 3/4"	Cylinder
501.HYD.6	501.SFT.6	9/32" x 1/2"	Cylinder

Max. RPM 10,000

### DIAMOLD®POLISHING BRUSHES (12 PER BOX)

These top quality brushes will hold diamond compounds longer and provide more cutting action at lower production costs. They are made of natural stiff bristle for long life.

Available in three shapes with long shank for straight handpieces and in three shapes with short shank for contra-angle handpieces.







Brush No.	Shank Diameter	Shape	Description
	Use these brushes with	any Straight Handpiece	
504.7HL	1/8"	End Shape	Plast Ferrule
504.7HS	3/32"	End Shape	Metal Ferrule
504.2HL	1/8"	Wheel Shape	Firm, natural bristles hold shape
504.2HS	3/32"	Wheel Shape	Firm, natural bristles hold shape
504.12HL	1/8"	Cup Shape	More bristles for longer life
504.12HS	3/32"	Cup Shape	More bristles for longer life
Use th	ese brushes with Contra-Angle H	andpiece only - for hard-to-get-at	places
504.73RC	3/32"	End Shape	
504.123RC	3/32"	Cup Shape	

### ABRA-CAP SEAMLESS THROW-AWAY CAPS (25 CAPS AND 1 HOLDER PER BOX)

For grinding, deburring, tool and die work, and other production operations, Abra-Caps are efficient and economical. They are seamless, with multi-coated abrasives that assure constant cutting efficiency and uniform surface feet per minute. After repeated uses, only the throwaway cap is discarded - no need to waste an entire tool because of dimensional change. The hard rubber holder is never exposed to wear.

17 sizes and shapes in two grit sizes to meet all requirements in working flat and curved surfaces, slots and grooves.





### Eye protection recommended

### Abra-Cap Replacement Series No. 61


Cap No.	Grit	Cap Diameter	Cap Length	Use Rubber Holder No.
506.5PC	80	.20	.40	506.5P
506.5PF	320			
506.10PC	80	.40	.63	506.10P
506.10PF	320			
506.16PC	80	.63	.79	506.16P
506.16PF	320			
506.5RC	80	.20	.40	506.5R
506.5RF	320			
506.10RC	80	.40	.63	506.10R
506.10RF	320			
506.16RC	80	.63	.79	506.16R
506.16RF	320			
506.5SC	80	.20	.40	506.5S
506.5SF	320			
506.10SC	80	.40	.63	506.10S
506.10SF	320			
506.16SC	80	.63	.79	506.16S
506.16SF	320			

### Abra-Cap Replacement Series No. 70

Cap No.	Grit*	Cap Diameter	Cap Smallest Length	Cap Length	Use Rubber Holder No.
506.5.CT	80	.20	.157	6.00	5/4 or 10/4
506.5.FT	150	.20	.157	6.00	5/4 or 10/4
506.10.CT	80	.40	.157	3.30	10/4
506.10.FT	150				
506.11.CT	80	.43	.354	1.00	11/9
506.11.FT	150				15/9
506.15.CT	80	.60	.354	3.30	15/9
506.15.FT	150				
506.16.CT	80	.63	.551	1.25	16/14
506.16.FT	150				20/14
506.20.CT	80	.79	.551	3.30	20/14
506.20.FT	150				
506.22.CT	80	.90	.748	1.60	22/19
506.22.FT	150				25/19
506.25.CT	80	1.00	.784	3.30	25/19
506 25 FT	150				

### ABRA-CAP SEAMLESS THROW-AWAY CAPS (25 CAPS AND 1 HOLDER PER BOX) (CONT.)





#### MOUNTED POINTS FOR MOLD AND DIE WORK

Engis® mounted abrasive points are designed specifically for mold and die work and include:

- Popular "B" and "W" shapes in both medium (red) and hard (blue) grades
- Assortments containing the most popular shapes

Points are manufactured from premium aluminum oxide and special bonding materials to assure rapid stock removal and long life.

### Ordering and Packaging:


Items shown in these listings are stocked and available for immediate shipment. All items are packaged in quantities of 25.





"B" Shapes Red & Blue Grades

### "B" SHAPES RED & BLUE GRADES



### MOUNTED POINTS FOR MOLD AND DIE WORK (CONT.)

"B" Shapes Red (Medium) & Blue (Hard) Grades

Shape	Size (in.) Dia.	Thickness	Mandrel (in.)	Red Grade Item No.	Blue Grade Item No.
B41	5/8	5/8	1/8	204181	204183
B42	1/2	3/4	1/8	204281	204283
B43	1/4	5/16	1/8		204383
B44	7/32	3/8	1/8	204481	204483
B45	3/16	5/16	1/8		204583
B51	7/16	3/4	1/8		205183
B52	3/8	3/4	1/8	205281	205283
B53	1/4	5/8	1/8	205381	205383
B55	1/8	1/4	1/8		205583
B71	5/8	1/8	1/8		207183
B72	1/2	1/8	1/8		207283
B81	3/4	3/16	1/8		208183
B82	1/2	1/4	1/8		208283
B91	1/2	5/8	1/8	209181	
B92	1/4	1/4	1/8	209281	
B96	1/8	1/4	1/8	209681	209683
B97	1/8	3/8	1/8		209783
B98	3/32	1/4	1/8		209883
B103	5/8	3/16	1/8		210383
B105	1/4	1/4	1/8		210583
B112	3/8	1/2	1/8		211283
B121	1/2	1/2	1/8		212183
B122	3/8	3/8	1/8	212281	212283
B123	3/16	3/16	1/8	212381	212383
B124	1/8	1/8	1/8	212481	212483
B125	1/4	1/4	1/8	212581	
B132	3/8	1/2	1/8	213281	
B133	3/8	3/8	1/8		213383
B135	1/4	1/2	1/8	213581	213583

Standard Packaging is 25

Eye protection recommended

### "W" Shapes Red (Medium) & Blue (Hard) Grades

Shape	Size (in.) Dia.	Thickness	Mandrel (in.)	Red Grade Item No.	Blue Grade Item No.
W140	1/4	5/64	1/8		214083
W141	3/32	5/32	1/8	214181	
W142	3/32	1/4	1/8	214281	214283
W144	1/8	1/4	1/8	214481	214483
W145	1/8	3/8	1/8	214581	214583
W146	1/8	1/2	1/8	214681	214683
W149	5/32	1/4	1/8		214983
W152	3/16	1/4	1/8	215281	
W153	3/16	3/8	1/8	215381	215383
W154	3/16	1/2	1/8	215481	215483
W160	1/4	1/4	1/8	216081	216083
W161	1/4	5/16	1/8		216183
W162	1/4	3/8	1/8	216281	216283
W163	1/4	1/2	1/8	216381	216383
W164	1/4	3/4	1/8		216483
W168	5/16	5/16	1/8		216883
W169	5/16	3/8	1/8	216981	
W170	5/16	1/2	1/8	217081	217083
W175	3/8	3/8	1/8		217583
W176	3/8	1/2	1/8	217681	217683
W178	3/8	1	1/8		217883
W182	1/2	1/8	1/8	218281	
W185	1/2	1/2	1/8		218583
W189	1/2	2	1/4	218941	
W200	3/4	1/8	1/8	220081	220083
W208	3/4	2	1/4	220841	
W216	1	1/4	1/8		221683
W220	1	1	1/4	222041	
W222	1	2	1/4	222241	
W225	1-1/4	1/4	1/4	222541	
W235	1-1/2	1/4	1/4	223541	
W236	1-1/2	1/2	1/4	223641	
W242	2	1	1/4	224241	

Standard Packaging is 25

### Kits: Item Number:

**Kit 1, 48 Points**: 299901


Three medium (red) and three hard (blue) each of the following: B44, B52, B96, B123, W144, W152, W162, W170, W175, & W200

**Kit 2, 100 Points:** 299902

Ten hard (blue) each of the following: B44, B52, B96, B123, W144, W152, W162, W170, W175 & W200

All "W" shapes are basically rectangular or square in their form. The diameter (D) and thickness (T) are detailed in the charts.

### Eye protection recommended



### **TUNGSTEN-CARBIDE CUTTERS (1 PER BOX)**

### For use with Air and Electric Rotary Handpieces.

The precision construction and design of the Engis®Tungsten-Carbide cutters makes them ideal for use on all materials from 25 RC thru 65 RC, including brass, cast iron, aluminum, bronze, fiberglass, plastics, etc.

These all-purpose cutters are ideal for hard to reach operations such as dies, small cavities, etc.

### Eye protection recommended



### 1/8" Shank Diameter - 1-1/2" Overall Length

1/0	Cutting	Head	Overall Length
Part No.	Diameter (D)	Length (L)	
EA1	1/16"	1/4"	
EA2	3/32"	7/16"	D
EA3	1/8"	9/16"	
EC4	3/32"	7/16"	
EC5	1/8"	9/16"	
ED6	3/32"	3/32"	-L-1
ED7	1/8"	1/8"	D
EE8	1/8"	7/32"	D
EF9	1/8"	1/4"	D
EF10	1/8"	1/2"	
EG11	1/8"	1/4"	
EG12	1/8"	3/8"	D
EH13	1/8"	1/4"	D
EJ14	1/8"	60°	D
EK15	1/8"	90°	
EL16	1/8"	8°	
EL17	1/8"	8°	
EM18	1/8"	12°	
EM19	1/8"	14°	D
EM20	1/8"	7°	
EN21	1/8"	10°	D

1/4" Cutting Head Diameter -1/8" Shank Diameter - 1" Shank Length

		i
Part No.	Cutting Head Length or Incl. Angle	
EA22	1/2"	D
EB23	3/16"	
EC24	1/2"	
ED25	1/4"	D
EE26	3/8"	D
EF27	1/2"	D
EG28	1/2"	D
EM29	22°	D
EN30	10°	D

### DIAMOND WHEELS AND POINTS (1 PER BOX)


### Single Layer - 3/32" Shanks

Fifteen shapes and a total of 49 sizes permit a broad selection of single layer diamond wheels and points for every type of grinding job. These tools are precision made with a special bond of metal plating that holds the diamonds in an exposed position for fast, constant cutting action.

• For long shank, used in all straight handpieces, specify "H" in ordering.



• For short shank, for contra-angle handpiece #55 only, specify "R" in ordering (see \* below)




### Eye protection recommended

	Part No.	D	d	t/h		
	DT124PH	602	.512	.018	1	↓   ← D →
	DT125PH	.721	.630	.018	, T	, <u>1</u>
Α	DT126PH	.799	.709	.020	1	
	DT127PH	.878	.787	.020		
В	DT74APH	.787	.276	.014		11.
	DT128PH	.361	.276	.020	Α	В
С	DT56PH	.343	.268	.051		
	DT132PH	.748	.453	.039		
D	DT129PH	.248	-	.020		
	DT105PH	.252	-	.035	t	→ D → H
E	DT107H	.102	-	.118	'    <b>  </b>	<u>- T</u>
	DT100H	.098	-	.276	# _	
	DT114H	.087	-	.276		<b>  </b>   <del>   </del>
	DB305H	.075	-	.196	H	
F	DT111H	.165	-	.059	D	E
	DT116H	.232	-	.236		
G	DT108H	.102	.059	.114		
	DT236H	.287	60°	.236		
н	DT93H	.201	27°	.374	101	
п	DT103AH	.169	80°	.106	<u> </u>	1 D
	DT94H	.122	31°	.189	***	#
	DT117H	.094	-	.295	7	<b>(1)</b>
1	DT510H	.094	-	.394		<b>  </b>
	DB902AH	.051	-	.158	G	Н
J	DT112H	.161	-	.059		
	DT109H	.366	-	.051		
	DB108H	.098	-	-		
	DB102H	.051	-	-	↓ <del> </del> D	→ D -
	DB2/0H	.032	-	-	†	
K	DB104H	.067	-	-	₩.	₩.
	DB105H	.071	-	-		
	DT101H	.118	-	-	HT	<b>11</b> 111
	DT119H	.158	-	-	J	K

### PRECISION PLUS ELECTROPLATED DIAMOND & CBN GRINDING PINS (1 PER BOX)

Featuring hardened steel shanks and bonded diamond or CBN particles, these precision grinding pins are ideal for use on jig and internal grinding machines and/or hand tools. Through our Electrogrip® process, particle exposure is maximized, assuring a free cutting action that greatly reduces heat and wear.

### Eye protection recommended





### BL (CBN) & GL (DIAMOND) SERIES PINS - SPECIFICATIONS

CBN Grit Size	Catalog Number	Diamond Grit Size	Catalog Number	Α	В	С
	BL.20		GL.20	.020	1/16"	1/8"
140/170	BL.25	Coarse (140/170)	GL.25	.025	3/32"	1/4"
140/170	BL.30	or Fine (200/230)	GL.30	.030	3/32"	1/4"
	BL.35		GL.35	.035	3/32"	1/4"
	BL.40		GL.40	.040	1/8"	3/8"
	BL.45	Coarse (140/170)	GL.45	.045	1/8"	3/8"
80/100	BL.50	or Fine (200/230)	GL.50	.050	1/8"	3/8"
	BL.50-1	, ,	GL.50.1	.050	1/8"	1"
	BL.55		GL.55	.055	1/8"	3/8"
	BL.60		GL.60	.060	1/8"	3/8"
80/100	BL.60.1		GL.60.1	.060	1/8"	1"
	BL.70	Coarse (140/170)	GL.70	.070	5/32"	1/2"
	BL.70.1	or Fine (200/230)	GL.70.1	.070	5/32"	1"
	BL.80		GL.80	.080	5/32"	1/2"
	BL.80-1		GL.80.1	.080	5/32"	1"
	BL.90		GL.90	.090	5/32"	1/2"
	BL.90-1		GL.90.1	.090	5/32"	1"
	BL.100		GL.100	.100	5/32"	1/2"
80/100	BL.100.1	Coarse (100/120)	GL.100.1	.100	5/32"	1"
00/100	BL.110	or Fine (200/230)	GL.110	.110	5/32"	1/2"
	BL.110-1		GL.110.1	.110	5/32"	1"
	BL.125		GL.125	.125	5/32"	1/2"
	BL.125-1		GL.125.1	.125	5/32"	1"
	BL.141		GL.141	.141	1/4"	-
	BL.156		GL.156	.156	1/4"	-
80/100	BL.188	Coarse (100/120)	GL.188	.188	1/4"	-
00/100	BL.218	or Fine (200/230)	GL.218	.218	1/4"	-
	BL.250/2		GL.250.2	.250	1/4"	-
	BL.250/4		GL.250.4	.250	1/4"	-


### MOUNTED POINTS FOR MOLD AND DIE WORK (CONT.)

These diamond-plated taper pins are ideal for grinding or ripping tungsten carbide drawing dies for the wire and ube industries, and for cold heading dies. You get fast, efficient and precise grinding, with long wear.

### Eye protection recommended

### Specifications:

Part No.	Α	В	С	
GLT.125.10	1/8"	2-1/2"	10°	
GLT.125.12	1/8"	2-1/2"	12°	
GLT.125.16	1/8"	2-1/2"	16°	
GLT.125.26	1/8"	2-1/2"	26°	
GLT.250.10	1/4"	3"	10°	
GLT.250.12	1/4"	3"	12°	
GLT.250.16	1/4"	3"	16°	
GLT.250.26	1/4"	3"	26°	





### G (DIAMOND) SERIES PINS — SPECIFICATIONS

Diamond Grit Size	Catalog Number	Α	В	С
	G.20	.020	1/16"	1/8"
Coarse (140/170)	G.25	.025	3/32"	1/4"
or Fine (200/230)	G.30	.030	3/32"	1/4"
	G.35	.035	3/32"	1/4"
	G.40	.040	1/8"	3/8"
Coarse (100/120)	G.45	.045	1/8"	3/8"
or Fine (200/230)	G.50	.050	1/8"	3/8"
,	G.55	.055	1/8"	3/8"
	G.60	.060	1/8"	3/8"
	G.70	.070	5/32"	1/2"
	G.80	.080	5/32"	1/2"
Coarse (100/120)	G.90	.090	5/32"	1/2"
or Fine (200/230)	G.100	.100	5/32"	1/2"
	G.110	.110	5/32"	1/2"
	G.125	.125	5/32"	1/2"

### BX (CBN) & GX (DIAMOND) SERIES PINS - SPECIFICATIONS

CBN Grit Size	Catalog Number	Diamond Grit Size	Catalog Number	А	В
	BX.141		GX.141	9/64"	1/4"
	BX.156		GX.156	5/32"	1/4"
	BX.188		GX.188	3/16"	1/4"
80/100	BX.218	Coarse (100/120)	GX.218	7/32"	1/4"
00/100	BX.250.2	or Fine (140/170)	GX.250.2	1/4"	1/8"
	BX.250.4		GX.250.4	1/4"	1/4"
	BX.312.2		GX.312.2	5/16"	1/8"
	BX.312.4		GX.312.4	5/16"	1/4"
	BX.312.6		GX.312.6	5/16"	3/8"
	BX.375.2		GX.375.2	3/8"	1/8"
	BX.375.4		GX.375.4	3/8"	1/4"
	BX.375.6		GX.375.6	3/8"	3/8"
80/100	BX.500.4	Coarse (100/120)	GX.500.4	1/2"	1/4"
80/100	BX.500.6	or Fine (140/170)	GX.500.6	1/2"	3/8"
	BX.500.8		GX.500.8	1/2"	1/2"
	BX.750.4		GX.750.4	3/4"	1/4"
	BX.750.8		GX.750.8	3/4"	1/2"

### **Engis® Superabrasive Tools**

# SUPERABRASIVE TOOLS®



Engis® offers state-of-the-art technology in the design of flat lapping systems that meet the most demanding requirements.

Engis® specializes in the design and manufacture of custom electroplated products, bringing our application and manufacturing experience together to provide high quality products, which exhibit superior performance, even in the most demanding applications.

Electrogrip® diamond and CBN electroplated grinding wheels and cutting tools are engineered to your exact requirements and designed to deliver unsurpassed productivity with consistent quality. We offer tailor-made grinding wheels, pins, dressing blocks and more specialty items.

We offer a complete range of superabrasive electroplated products for precision applications. Engis\* also manufactures electroplated products for more demanding applications such as ceramics, fiberglass pipe, and composites.

- · Superabrasive wheels
- · Diamond blocks & tools
- Diamond pins & mandrels
- · Diamond saw blades
- · Specialized tools

At Engis® we work hand-in-hand with you to design grinding products for even the most demanding applications. This can include the grinding of gray iron parting lines, threading of fiberglass oil field pipe, precision grinding of high nickel alloy jet engine components, or the final pass on surgical needles.

Contact your Engis® Regional Sales Manager or local distributor to discuss the difficult applications that you may be facing.







## FINISHING STICKS

## DiaMold® Lapping Sticks


### **DIAMOLD® LAPPING STICKS**

### **Hard Wood Lapping Sticks:**

Laminated 6" lapping sticks are designed especially for fast stock removal using Engis® diamond compounds. Made of highly compressed wood layers with alternating grain direction, saturated and bonded with synthetic resin, they are dense, easily formed, shape retaining, and perform like a cast iron lap of top quality such as Meehanite. The many shapes available include square and rectangular with 45° bevels or round with conical points.

### **Soft Wood Lapping Sticks:**

Designed for immediate and final polishing. Square and rectangular shapes are beveled to  $45^{\circ}$ ; round sticks are pointed. All shapes are  $6^{\circ}$  long.



### **Wood Selection**

### All One Size and Wood Hardness Contained in Each Package

Hard	Soft	In Each Pack	Size	Shape
502.D	502.SD	1	1/8" x 1/8" x 6"	Square
502.E	502.SE	1	1/8" x 1/4" x 6"	Rectangle
502.F	502.SF	1	1/4" x 1/4" x 6"	Square
502.G	502.SG	1	3/16" x 3/16" x 6"	Square
502.H	502.SH	1	5/16" x 1/2" x 6"	Rectangle
502.I	502.SI	1	5/16" x 3/4" x 6"	Rectangle
502.J	502.SJ	1	1/8" x 6"	Round
502.K	502.SK	1	3/16" x 6"	Round
502.L	502.SL	1	1/4" x 6"	Round

### SPECIAL GROUP COMBINATIONS OF LAPPING STICKS

### **Wood Selection**

### All One Size and Wood Hardness Contained in Each Package

Hard	Soft	In Each Pack	Size	Shape
		6	1/8" x 1/8" x 6"	Square
		6	1/8" x 1/4" x 6"	Rectangle
Croup EO2 A	Croup E02 CA	4	1/4" x 1/4" x 6"	Square
Group 502.A	Group 502.SA	4	3/16" x 3/16" x 6"	Square
		2	5/16" x 1/2" x 6"	Rectangle
		2	5/16" x 3/4" x 6"	Rectangle
		12	1/8" x 1/8" x 6"	Square
Group 502.B	Group 502.SB	12	1/8" x 1/4" x 6"	Rectangle
		12	1/4" x 1/4" x 6"	Square
Croup E02 C	Croup FO2 SC	5	5/16" x 1/2" x 6"	Rectangle
Group 502.C	Group 502.SC	5	5/16" x 3/4" x 6"	Rectangle
Group 502.M		10	1/8" x 6"	Round
	Group 502.SM	8	3/16" x 6"	Round
		4	1/4" x 6"	Round




## **STONES**

## DiaMold® Polishing Stones

Engis® offers a complete range of vitrified finishing stones for hand and machine polishing applications. Our stones come in a wide variety of grit sizes and formulations to provide you with the right tool for each job.

DiaMold® stones are available in both standard and premium white aluminum oxide as well as green silicon carbide to cover a broad range of mold materials. Please consult the chart below to identify the right stone for your application.






Page	Туре	Abrasive	Color	Grits	Characteristics & Application
87	DM	Aluminum Oxide	Gray	150-600	Similar to the DS general purpose finishing stone. This stone is slightly harder and does not break down as rapidly as the DS. Engineered to cut very fast, yet provide a smooth finish. Excellent for removing cutter marks on all tool and die steels.
87	EDM	White Aluminum Oxide	Dark Brown	100-600	The EDM stone is engineered for the removal of EDM scale. This stone is a soft grade which breaks down fast and cuts freely. Specially designed for hand applications.
88	RG	Green Silicon Carbide	Green	120-600	A medium stone with premium silicon carbide grains. Cuts very fast, yet provides an excellent finish on most die and mold steel types ranging from 28 to 58 Rc. Also permits finishing on aluminum, cast iron and bronze.
88	DS	Regular Aluminum Oxide	Green / Tan	100-900	Very popular medium hard stone for all types of steel. Fast cutting, provides a fine, even finish and has the perfect breakdown for a finishing stone.
89	A/L	White Aluminum Oxide	Tan	150-600	A specially treated, medium hard stone that cuts fast and leaves an excellent finish. It works well on aluminum,not scratching or tearing the surface.
90	НҮ	White Aluminum Oxide	Cream / Ivory	120-600	Extremely well liked, this medium hard stone is treated with a special oil to resist loading. Cuts very fast yet provides smooth finishes on most tool and die sheets. 220 grit and 320 grits work well on hard EDM scale.

DM

Similar to the DS general purpose finishing stone. This aluminum oxide stone is slightly harder and does not break down as rapidly as the DS. Engineered to cut very fast yet provides a smooth finish.

Excellent for removing cutter marks on all tool and die steels.

- General purpose
- · Fast cutting
- Consistent breakdown
- · For use on all tool steels





Size (inch)	Pcs/ Box	150	180	220	320	400	600
1/16 x 1/4 x 6	12	0810179		0812039	0813239	0814059	0816119
1/16 x 1/2 x 6	12	0810129		0812109	0813249	0814099	0816209
1/8 x 1/8 x 6	12	0810159	0811129	0812159	0813299	0814129	0816259
1/8 x 1/4 x 6	12	0810199	0811179	0812239	0813339	0814199	0816299
1/8 x 1/2 x 6	12	0810229	0811239	0812259	0813359	0814219	0816319
1/8 x 1 x 6	12	0810259	0811289	0812319	0813369	0814229	0816339
5/32 x 5/32 x 6	12	0810309	0811359	0812359	0813399	0814259	0816399
1/4 x 1/4 x 6	12	0810379	0811399	0812369	0813409	0814369	0816409
1/4 x 1/2 x 6	12	0810429	0811429	0812429	0813429	0814429	0816429
1/4 x 1 x 6	6	0810459	0811499	0812739	0813499	0814499	0816469
3/8 x 3/8 x 6	12	0810489		0812789	0813539	0814529	0816559
1/2 x 1/2 x 6	6	0810539	0811549	0812839	0813549	0814559	0816629
1/2 x 1 x 6	4	0810579	0811579	0812869	0813559	0814609	0816649
1 x 1 x 6	2	0810629	0811639	0812899	0813599	0814659	0816699
1/4 TRI x 6	6	0810659		0812909	0813619	0814699	
3/8 TRI x 6	6	0810699		0812919	0813649	0814709	
1/4 RND x 6	6	0810739		0812959	0813679	0814889	0816709
3/8 RND x 6	6	0810789		0812979	0813719	0814899	0816759
1/2 RND x 6	6	0810999		0812999	0813749	0814959	

### **EDM**

The EDM stone is engineered for the removal of EDM scale. This white aluminum oxide stone is a soft grade which breaks down fast and cuts freely. Specially designed for hand application.

Size (inch)	Pcs/ Box	100	120	150	180	220
1/16 x 1/4 x 6	12		0212609	0213709	0214809	0215909
1/16 x 1/2 x 6	12	0211609	0212709	0213809	0214909	0216009
1/8 x 1/8 x 6	12				0215009	0216109
1/8 x 1/4 x 6	12	0211809	0212909	0214009	0215109	0216209
1/8 x 1/2 x 6	12	0211909	0213009	0214109	0215209	0216309
1/8 x 1 x 6	12	0212009	0213109	0214209	0215309	0216409
5/32 x 5/32 x 6	12		0213209		0215409	0216509
1/4 x 1/4 x 6	12	0212309	0213409	0214509	0215609	0216709
1/4 x 1/2 x 6	12	0212409	0213509	0214609	0215709	0216809
1/4 x 1 x 6	6	0212509	0213609	0214709	0215809	0216909

**87** 

### EDM (CONT.)

Size (inch)	Pcs/ Box	280	320	400	600
1/16 x 1/4 x 6	12	0217009	0218109	0219209	0221409
1/16 x 1/2 x 6	12	0217109	0218209	0219309	0221509
1/8 x 1/8 x 6	12		0218309	0229409	0221609
1/8 x 1/4 x 6	12	0217309	0218409	0219509	0221709
1/8 x 1/2 x 6	12	0217409	0218509	0219609	0221809
1/8 x 1 x 6	12	0217509	0218609	0219709	
5/32 x 5/32 x 6	12		0218709	0219809	0222009
1/4 x 1/4 x 6	12	0217809	0218909	0220009	0222209
1/4 x 1/2 x 6	12	0217909	0219009	0220109	0222309
1/4 x 1 x 6	6	0218009	0219109	0220209	0222409

### RG

A medium stone with premium silicon carbide grains. Cuts very fast, yet provides an excellent finish on most die and mold steel types ranging from 28 to 58 Rc. Also permits finishing on aluminum, cast iron and bronze.

Size (inch)	Pcs/ Box	120	150	220	320	400	600
1/16 x 1/2 x 6	12		0352059	0353059	0355059	0356059	0358059
1/8 x 1/4 x 6	12	0351139	0352139	0353139	0355139	0356139	0358139
1/8 x 1/2 x 6	12	0351179	0352179	0353179	0355179	0356179	0358179
5/32 x 5/32 x 6	12				0355259	0358259	0358259
1/4 x 1/4 x 6	12	0351299	0352299	0353299	0355299	0356299	0358299
1/4 x 1/2 x 6	12	0351339	0352339	0353339	0355339	0356339	0358339
1/4 x 1 x 6	6		0352379	0353379	0355379	0356379	0358379
3/8 x 3/8 x 6	12		0352419	0353419	0355419	0356419	
1/2 x 1/2 x 6	6		0352459	0353459	0355459	0356459	0358459
1/2 x 1 x 6	4		0352499	0353499	0355499	0356499	0358499
1 x 1 x 6	2		0352539	0353539	0355539	0356539	0358539
1/4 RND x 6	6			0353739	0355739	0356739	

### DS

Very popular medium hard aluminum oxide stone for all types of steel. Fast cutting - provides a fine, even finish and has the perfect breakdown for a finishing stone.

Size (inch)	Pcs/ Box	100	150	180	220	280
1/16 x 1/4 x 6	12	0232109	0233409		0236009	0237309
1/16 x 1/2 x 6	12	0232209	0233509		0236109	
1/8 x 1/8 x 6	12	0232309	0233609	0234909	0236209	
1/8 x 1/4 x 6	12	0232409	0233709	0235009	0236309	0237609
1/8 x 1/2 x 6	12	0232509	0233809	0235109	0236409	0237709
1/8 x 1 x 6	12	0232609	0233909	0235209	0236509	0237809
5/32 x 5/32 x 6	12	0232709	0234009	0235309	0236609	
1/4 x 1/4 x 6	12	0232909	0234209	0235509	0236809	0238109
1/4 x 1/2 x 6	12	0233009	0234309	0235609	0236909	0238209
1/4 x 1 x 6	6	0233109	0234409	0235709	0237009	0238309
3/8 x 3/8 x 6	12	0233159	0234459		0237059	0238359
1/2 x 1/2 x 6	6	0233209	0234509	0235809	0237109	0238409
1/2 x 1 x 6	4	0233309	0234609	0235909	0237209	0238509
1 x 1 x 6	2	0233319	0234619	0235919	0237219	
1/4 TRI 6	6		0234639		0237239	
3/8 TRI x 6	6		0234649		0237249	
1/4 RND x 6	6		0234669		0237269	
1/2 RND x 6	6		0234689		0237289	
3/8 RNDx 6	6		0234679		0237279	

### DS (CONT.)

Size (inch)	Pcs/ Box	320	400	600	900
1/16 x 1/4 x 6	12	0238609	0239909	0242509	
1/16 x 1/2 x 6	12	0238709	0240009	0242609	
1/8 x 1/8 x 6	12	0238809	0240109	0242709	
1/8 x 1/4 x 6	12	0238909	0240209	0242809	0245409
1/8 x 1/2 x 6	12	0239009	0240309	0242909	0245509
1/8 x 1 x 6	12	0239109	0240409	0243009	
5/32 x 5/32 x 6	12	0239209	0240509	0243109	0245709
1/4 x 1/4 x 6	12	0239409	0240709	0243309	0245909
1/4 x 1/2 x 6	12	0239509	0240809	0243409	0246009
1/4 x 1 x 6	6	0239609	0240909	0243509	0246109
3/8 x 3/8 x 6	12	0239659	0240959	0243559	
1/2 x 1/2 x 6	6	0239709	0241009	0243609	0246209
1/2 x 1 x 6	4	0239809	0241109	0243709	
1 x 1 x 6	2	0239819	0241119	0243719	
1/4 TRI 6	6	0239839	0241139		
3/8 TRI x 6	6	0239849	0241149		
1/4 RND x 6	6	0239869	0241169	0243769	
1/2 RND x 6	6	0239889	0241189		
3/8 RNDx 6	6	0239879	0241179	0243779	

### A/L

A specially treated, medium hard white aluminum oxide stone that cuts freely and leaves an excellent finish. It works well on aluminum, not scratching or tearing the surface.

Size (inch)	Pcs/ Box	150	220	320	400	600
1/8 x 1/4 x 6	12	0381929	0383529	0384329	0385129	0385929
1/8 x 1/2 x 6	12	0381969	0383569	0384369	0385169	0385969
1/4 x 1/4 x 6	12	0382089	0383689	0384489	0385289	0386089
1/4 x 1/2 x 6	12	0382129	0383729	0384529	0385329	0386129
1/4 x 1 x 6	6	0382169	0383769	0384569	0385369	0386169

### НΥ

Favored by professionals, this medium hard white aluminum oxide stone is treated with a special oil to resist loading. It cuts very fast yet provides smooth finishes on most tool and die sheets. 220 grit and 320 grits work well on hard EDM scale.

Size (inch)	Pcs/ Box	120	150	220	320	400	600
1/16 x 1/4 x 6	12	0331019	0332019	0334019	0336019	0337019	0339019
1/16 x 1/2 x 6	12	0331059	0332059	0334059	0336059	0337059	0339059
1/8 x 1/8 x 6	12	0331099	0332099	0334099	0336099	0337099	0339099
1/8 x 1/4 x 6	12	0331139	0332139	0334139	0336139	0337139	0339139
1/8 x 1/2 x 6	12	0331179	0332179	0334179	0336179	0337179	0339179
1/8 x 1 x 6	12	0331219	0332379	0334219	0336219	0337219	
5/32 x 5/32 x 6	12	0331259	0332259	0334259	0336259	0337259	0339259
1/4 x 1/4 x 6	12	0331299	0332299	0334299	0336299	0337299	0339299
1/4 x 1/2 x 6	12	0331339	0332339	0334339	0336339	0337339	0339339
1/4 x 1 x 6	6	0331379	0332219	0334379	0336379	0337379	0339379
3/8 x 3/8 x 6	12	0331419	0332419	0334419	0336419	0337419	
1/2 x 1/2 x 6	6	0331459	0332459	0334459	0336459	0337459	0339459
1/2 x 1 x 6	4	0331499	0332499	0334499	0336499	0337499	0339499
1 x 1 x 6	2	0331539	0332539	0334539	0336539	0337539	0339539
1/4 TRI x 6	6				0336699	0337699	
3/8 TRI x 6	6	0331739		0334739		0337739	
1/2 TRI x 6	6	0331779					
1 TRI x 6	4	0331819					
1/4 RND x 6	6	0331899	0332899	0334899	0336899	0337899	0339899
3/8 RND x 6	6	0332939		0334939	0336939	0337939	0339939
1/2 RND x 6	6			0334979	0336979	0337979	0339979

### POLISHING STONE APPLICATION CHART

		Surface		Method		Use					
		Tool Steel	Aluminum	Non- Ferrous	Stainless Steel	EDM	Hand	Profiler	Ultrasonic	Dry	Wet
EDM Stone	EDM	•				•	•	•		•	•
General Purpose	DS	•	•	•	•		•	•		•	•
	RB	•	•				•	•		•	•
	DM	•	•	•	•		•	•		•	•
	A/L	•	•				•	•			•
Specialty Stones	НҮ	•				•	•	•			•
	ROM	•					•	•		•	•
Silicon Carbide Stone	RG	•	•	•			•	•		•	•

### DiaMold® Ceramic Stones

DiaMold® ceramic stones are made from the finest ceramic fiber with a special resin binder and were originally developed for the aerospace industry. These virtually unbreakable polishing stones work well in the finishing of small detail areas such as slots, ribs and other narrow areas of molds and dies. They can be used either by hand or with a reciprocating or ultrasonic Diprofil® polishing system.

Since these high quality ceramic stones can be easily shaped and come in a broad range of sizes and grits, they are one of the most versatile tools for precision finishing of molds and dies.

### Usage:

- Precision finishing of ribs, edges, etc., on dies and molds.
- No loading or clogging of the stone even on some materials such as aluminum.
- Can be used in very narrow areas without the risk of breakage.
- Can be used on complex shapes where uniform finishing can be a challenge.
- Can be used by hand or with Diprofil reciprocating or rotary systems.

## TECHNICAL DATA

- · High strength, resists breakage
- · High efficiency
- Uniform finishes
- · Resists loading or clogging
- · Low heat generation
- · Efficient cleaning of EDM scale
- · Fast removal of fine burrs
- · Variety of grits available

#### **Stone Holders**



Number	Length	Width of Stick	
29950	For Profiler	1/8" Mandrel	Α
29925	5-1/2"	3mm round	В
29940	5-3/4"	8-10mm stick	С
29935	5-3/4"	6mm stick	D
29930	5-3/4"	2-4mm stick	E
29945	Set of	above three	

Shape	Size (mm)	Green 120 Grit P/N	Gold 180 Grit P/N	Orange 220 Grit P/N	Light Brown 300/320 Grit P/N	Orange 400 Grit P/N
Flat	1 x 4 x 50	CS120.10	CS180.10			
Flat	.5 x 2 x 100	CS120.15	CS180.15	CS052100DB	CS300.15	CS400.15
Flat	.5 x 4 x 100	CS054100G	CS054100LB		CS300.20	CS400.20
Flat	.5 x 6 x 100	CS120.25	CS180.25		CS300.25	CS400.25
Flat	.8 x 4 x 100	CS120.30	CS180.30		CS300.30	CS084100B
Flat	.8 x 6 x 100	CS120.35	CS086100LB		CS086100DB	CS086100B
Flat	.8 x 10 x 100	CS120.40	CS180.40		CS300.30	
Flat	1 x 2 x 100	CS120.45	CS180.45		CS12100DB	CS12100B
Flat	1 x 4 x 100	CS14100G	CS14100LB		CS14100DB	CS14100B
Flat	1 x 6 x 100	CS16100G	CS180.55		CS300.55	CS400.55
Flat	1 x 10 x 100	CS120.60	CS110100LB	CS110100O	CS110100DB	CS110100B
Flat	1.5 x 4 x 100	CS120.65	CS180.65		CS300.65	CS400.65
Flat	1.5 x 6 x 100	CS120.70	CS180.70		CS300.70	CS156100B
Round	2.35 x50					CS400.75
Round	3 x 50	CS120.80	CS180.80		CS300.80	CS400.80
Round	3.16 x 50	CS120.85	CS180.85		CS300.85	CS400.85
Round	3 x 100	CS120.90	CS3100LB		CS300.90	CS400.90

Shape	Size (mm)	Black 600 Grit P/N	Blue 800 Grit P/N	White 1000 Grit P/N	Red 1200 Grit P/N
Flat	1 x 4 x 50	CS600.10	CS800.10		
Flat	.5 x 2 x 100	CS600.15	CS800.15	CS1000.15	CS1200.15
Flat	.5 x 4 x 100	CS600.20	CS800.20	CS1000.20	CS1200.20
Flat	.5 x 6 x 100	CS600.25	CS800.25	CS056100R	CS1200.25
Flat	.8 x 4 x 100	CS600.30	CS800.30	CS1000.30	CS1200.30
Flat	.8 x 6 x 100	CS600.35	CS800.35	CS1000.35	CS1200.35
Flat	.8 x 10 x 100	CS600.40	CS800.40	CS1000.40	
Flat	1 x 2 x 100	CS600.45	CS800.45	CS1000.45	CS1200.45
Flat	1 x 4 x 100	CS600.50	CS800.50	CS14100R	CS1200.50
Flat	1 x 6 x 100	CS600.55	CS800.55	CS1000.55	CS1200.55
Flat	1 x 10 x 100	CS600.60	CS110100W	CS110100R	CS1200.60
Flat	1.5 x 4 x 100	CS600.65	CS800.65	CS1000.65	CS1200.65
Flat	1.5 x 6 x 100	CS600.70	CS800.70		
Round	2.35 x50	CS600.75	CS800.75		CS1200.75
Round	3 x 50	CS600.80	CS800.80	CS1000.80	CS1200.80
Round	3.16 x 50	CS600.85	CS800.85	CS1000.85	CS1200.85
Round	3 x 100	CS600.90	CS800.90	CS3100R	CS1200.90



# **ACCESSORIES**

## DiaMold® Polishing Stone Holders

A selection of Polishing Stone Holders is available from Engis®. Holders for hand and machine polishing are listed below.





Part No.	
299239	Profiler vise type stone holder, 3/16" shank - for Profiler

		**
В	299249	Profiler vise type stone holder, 1/8" shank - for Profiler
С	299609	Holder Pro for 1/4" Stone (Long), 3/16" shank - for Profiler
D	299639	Holder Pro for 1/4" Stone (Short), 3/16" shank - for Profiler
E	299679	Holder Pro for 1/8" Stone (Short), 3/16" shank - for Profiler
F	299549	Holder Pro for 1 mm ceramic stone, 3/16" shank
G	29915	4 piece hand stone holder kit. Holds round & all sizes of square & rectangular polishing stones from 1/16" to 1/2"
K	299199	1/8" x 1/2" & 1/4" x 1/4" - 1/8" Shank - for Profiler
L	299189	1/8" x 1/4" - 1/8" Shank - for Profiler
М	299169	1/8" x 1/4" - 3/16" Shank - for Profiler
N	299179	1/8" x 1/4" & 1/4" x 1/4" - 3/16" Shank - for Profiler

Ρ Α

## Stones, Lapping Stick & File Holders

The DiaMold $^{\circ}$  Stone and Stick Holder (VEA) will hold sticks and stones up to 1/2" diameter, round, square and rectangular at an angle for those hard-to-reach operations (45 to 90 $^{\circ}$  angles).

The VEA is used with the Di-Profiler Reciprocating Hand Machine. It is designed to add greater flexibility to lapping operations.

A. FH.1 - File Holder

B. VEA - Stick & Stone Holder

C. FVA - File & Shoe Holder

D. 29950 - Hyprez Ceramic Stone Holder

E. IF-20 - File Holder



### STONE HOLDER KIT WITH ACCESSORIES - PART NO. 508.SHK 101

Kit includes one of each:

- Holder VEA
- Abrasive Stones: 1/4" x 1/2" x 6" (Stone Part Numbers: 0249109, 0254709, 0356339, 0358339, 0286409)
- Hyprez Lapping Sticks: D, SE, F, SG, H, SJ, K and SL



## **WELDING UNITS**

## **SST Microwelding - LASER QUALITY**

Specializing for more than thirty years in microwelding equipment, SST Microwelders offer plasma arc spot welding, TIG, and high speed spot welding.

### LASE ONE 300i - THE MOST POWERFUL WELDING SOLUTION OF THE LASE ONE RANGE

### Lase One 300i includes:

- · Welding generator Lase One 300 joules
- Stereo binocular microscope with articulated arm, equipped with controlled shutter (zoom X4/X20 with cold lighting by LED)
- · 2 wrist foam rests
- · Microwelding torch (length: 1.5M)
- · Foot control pedal (length: 2.0M)
- · Accessories for microwelding torch
- Ground cable (length: 2.0M)
- Power supply: 220/240V, single phase + ground



**Bronze** 



Aluminum



Steel



Copper

### **FEATURES & BENEFITS**

- · Plasma arc spot welding (0-300 joules)
- · Weld time adjustable to the tenth of a millisecond (pulse duration 0.1 to 10 ms)
- · Weld quality and aspect very similar to that of laser weld
- · Welding of ferrous/ non-ferrous/ precious materials (gold, silver, etc.)
- · No overheating/ deformations
- Reliable and easy to use
- · Economical and safe
- · Easy assembly and repair welds of very small as well as large parts
- Programmable



95

### **ELECTRODES SHARPENER**

Electrical portable grinder for Lase One electrodes, reliable and easy to use with variable speed control. The high quality of sharpening improves starting arc, especially for precise low intensity discharge. Diamond disk for spare parts available ref L1-DRAFLC.

### **TECHNICAL DATA**

- Precise sharpening in longitudinal direction, through a replaceable diamond cutting wheel
- · Standard sharpening angle of 30°
- Power supply: 110/230V 50/60Hz
- Max. speed 20,000 rpm
- · Delivered with electrode holding pencil



Electrode sharpener : L1-AFLC Diamond disk : L1-DRAFLC

#### CONTROLLED SHUTTER WELDING MASK

### **TECHNICAL DATA**

- · Welding helmet for Lase One generator
- · Lenses x 2.5 magnification
- · LCD shutter generator unit driven



L1-MS

### **CART**

Mobile serving cart equipped by electric cylinder operated by remote control. To use with extended cables.



CART

#### **CLEANING PEN**

Fiber glass cleaning pen for micro-welding, including one refill.



Cleaning pen: SST-CN Set of 10 refills: SST-CN-R10

### **MANUAL WIRE FEEDER**

Manual Wire feeder for diameter wire from 0.2mm up to 0.6mm, indispensable for small diameter.



SST-GF

## **ELECTRODES**

		Quantity
ELA20-1070-10	Lase-1 electrodes Ø 1.0 x 70 mm (x10)	2
ELA20-1670-10	Lase-1 electrodes Ø 1.6 x70 mm (x10)	2
ELA20-2470-10	Lase-1 electrodes Ø 2.4 x70 mm (x10)	2

### **WELDING WIRES**

Welding Wires (per meter)						
SST-12330-03	Laser welding wire 1,2330 (P20) - Ø0.3	5				
SST-12330-06	Laser welding wire 1,2330 (P20) - Ø0.6	5				
SST-12344-03	Laser welding wire 1,2344 (H13) - Ø0.3	5				
SST-12344-06	Laser welding wire 1,2344 (H13) - Ø0.6	5				
SST-14430-03	Laser welding wire 1,4430 (316L) - Ø0.3	5				
SST-14430-06	Laser welding wire 1,4430 (316L) - Ø0.6	5				

### **DEMONSTRATION**

To view a Lase One demonstration, visit www.sstmicrowelding.com/en/videos Please give us a call for additional size wires: 847/808-9400 / info@engis.com









# ACCESSORIES

## **Mold Medic Supplies**

### WELDING ROD/WIRE MATERIAL

Item No.	Material	Diameter	Length
W4001-0.8	P-20	0.032"	78-3/4"
W4001-0.6	P-20	0.023"	78-3/4"
W4001-0.4	P-20	0.015"	78-3/4"
W4002-0.8	P-21	0.032"	78-3/4"
W4003-0.8	H-13	0.032"	78-3/4"
W4003-0.6	H-13	0.023"	78-3/4"
W4003-0.3	H-13	0.011"	78-3/4"
W4004-0.8	D2,A2	0.032"	78-3/4"
W4004-0.6	D2,A2	0.023"	78-3/4"
W4004-0.4	D2,A2	0.015"	78-3/4"
W4005-0.8	STAVAX	0.032"	78-3/4"
W4005-0.6	STAVX	0.023"	78-3/4"
W4006-0.8	M2,D2,S7	0.032"	78-3/4"
W4006-0.6	M2,D2,S7	0.023"	78-3/4"
W4006-0.4	M2,D2,S7	0.015"	78-3/4"
W4007-0.8	RIGOR	0.032"	78-3/4"
W4008-0.8	ORVAR	0.032"	78-3/4"
W4009-0.8	IMPAX	0.032"	78-3/4"
W4010-0.8	MAS-1	0.032"	78-3/4"



### **Metal Ribbon**

Item No.	Material	Hardness (Rc)	Size (in)
W2004	P-20	30-50	.196x.004x40
W2004-1	P-20	30-50	.196x.008x40
W2002	P-21	38-40	.196x.004x40
W2002-1	P-21	38-40	.196x.008x40
W2005	420SS	30-33	.196x.004x40
W2005	420SS	30-33	.196x.008x40

### **Powder Metal**

Item No.	Material	Hardness (Rc)	Quantity
W2031	P-20	30-50	50 grams
W2033	P-21	38-40	50 grams
W2032	420SS	30-33	50 grams

### Paste Metal

Item No. Material		Hardness (Rc)	Size (in)
W2033-1	P-21	38-40	50 grams
W2032-1	420SS	30-33	50 grams

### **Porous Metal**

Item No.	Material	Thickness	Size (in)
W2054	420SS	.027"	.196x40
W2051	316LSS	.027"	2x3

### Yarn Metal

Item No.	Material	Description	Unit
W2062	P-20	Steel Wool Type	Plastic Jar
W2065	P-21	Steel Wool Type	Plastic Jar

### **ELECTRODES**

Mold Medic			Magnetic		
Number	Description	Size	Number	Description	Size
W1009	Pointed, .078" Diameter	2" long	W1015	Round, .078" Diameter	2" long
W1010	Round, .078" Diameter	2" long	W1016	Round, .118" Diameter	2" long

## Please give us a call for additional sizes: 847/808-9400 / info@engis.com





## **GLOBAL REACH**



## INFO@ENGIS.COM 847/808-9400



Beginning-to-end flat finishing systems

– machines, plates, pads, diamond powders, slurries, lubricants and other accessories

– plus customized equipment, specialized formulas, testing labs and technical support for process and technology development.

### Hyprez®DiaMold® Toolroom Products



Comprehensive line of diamond polishing compounds, abrasive stones, sticks, bobs, brushes and files – plus powered hand finishing systems for every toolroom application.

### Engis® Single-Pass Bore Finishing Systems



Single-pass bore finishing systems-standard models and custom machines-plus diamond and CBN plated finishing tools, parts holders/ fixtures and integrated automation systems.



Advanced superabrasive grinding, cutting and dressing systems utilizing diamond and CBN materials. Specializing in the aerospace, medical, ceramic, automotive, and composite industries.

### **ENGIS® CORPORATION**

**Leaders in Superabrasive Finishing Systems** 

105 W. Hintz Road • Wheeling, IL 60090-6038 Phone: 847/808-9400 • Toll Free: 1-800-99-ENGIS Fax: 847/808-9430 • E-Mail: info@engis.com

Website: www.engis.com

